

Essential Information

MKZ Quick Reference Guide

About Your Leather Seats – Your leather seats have a clear, protective coating over them which requires special care. Use only Motorcraft Deluxe Leather and Vinyl Cleaner (ZC-11-A). Dry with a soft cloth. Do not use any household cleaning products or oil/petroleum-based conditioners as they may cause premature wearing of the protective coating.


Location of Spare Tire and Tools – If you get a flat tire while driving, do not apply the brake heavily. Instead, gradually decrease your speed. Hold the steering wheel firmly and slowly move to a safe place on the side of the road. Your vehicle is equipped with a temporary spare tire. The spare tire, jack and tool bag are located under the carpeted floor panel in the trunk. The temporary spare is designed for emergency use only and should be replaced as soon as possible. For complete details on how to change your tire, refer to the Roadside Emergencies chapter in your Owner's Guide.

Fuses – If the vehicle's electrical components are not operating, a fuse may have blown. The fuse panel is located below the instrument panel on the driver's side; remove the cover to view the fuses. Additional fuses are located in the power distribution box in the engine compartment. For more information regarding changing fuses, refer to the Roadside Emergencies chapter in your Owner's Guide.

Fuel Type and Tank Capacity – Front Wheel Drive (FWD) vehicles have a fuel tank capacity of 17.5 gallons (66.2L) while All Wheel Drive (AWD) vehicles have a fuel tank capacity of 16.5 gallons (62.4L). Your vehicle is designed to use "Regular" unleaded gasoline with an octane rating of 87. Do not use gasoline labeled as "Regular" in high altitude areas that are sold with octane ratings less than 87. Do not use E85 fuels as your vehicle was not designed to run on E85 fuels that are blended with a maximum of 85% ethanol.

This Quick Reference Guide is not intended to replace your vehicle Owner's Guide which contains more detailed information concerning the features of your vehicle, as well as important safety warnings designed to help reduce the risk of injury to you and your passengers. Please read your entire Owner's Guide carefully as you begin learning about your new vehicle and refer to the appropriate sections when questions arise. All information contained in this Quick Reference Guide was accurate at the time of duplication. We reserve the right to change features, operation and/or functionality of any vehicle specification at any time. Your Lincoln dealer is the best source for the most current information. For detailed operating and safety information, please refer to your Owner's Guide. Ford Motor Company, Customer Relationship Center, P.O. Box 6248, Dearborn, MI 48121 1-800-992-3673 (FORD), TDD for the hearing impaired: 1-800-232-5952

April 2008
First Printing
Quick Reference
Guide
Lincoln MKZ
Litho in USA



9H6J 19G217 AA

Additional Features

MKZ Quick Reference Guide

Memory Feature

The memory feature enables the vehicle to "remember" the position of your driver seat and exterior mirrors. To set, position the driver's seat and exterior mirrors where you want them. Press SET on the driver's door panel. Within five seconds, the tire pressure monitoring system (TPMS) that illuminates a low tire pressure warning light (L) when one or more of your tires is significantly under-inflated. **Warning:** Improperly inflated tires can affect vehicle handling and can fail suddenly, resulting in a possible loss of vehicle control. Refer to the Tires, Wheels and Loading chapter in your Owner's Guide for further information.

Integrated Keyhead Transmitter and Remote Entry System Features

IKTs are both a programmed ignition key and a remote keyless entry transmitter. Handle the IKT carefully when starting the car to avoid accidentally pressing any of the remote entry buttons. Press (L) once to unlock the driver's door. The interior lamps will illuminate. Press (L) twice to unlock all the doors. Press (L) once to lock all the doors and activate the perimeter alarm system. The turn lamps will flash. Press (L) twice to confirm all the doors and trunk are closed. The horn will chirp and the turn signal lamps will flash once if all the doors and the trunk are closed. Press (L) to activate the panic alarm. (Press again or turn the ignition on to deactivate.) Press (L) twice within 3 seconds to open the trunk. Press (L) twice within 3 seconds to activate the car finder; the horn will chirp and the turn lamps will flash. It is recommended that this method be used to locate your vehicle, rather than using the panic alarm. Ensure that you keep the IKT adhesive security label in a safe place for future reference.

Fuel Pump Shut-Off Switch – The fuel pump shut-off switch stops the electric fuel pump from sending fuel to your engine when your vehicle has sustained a substantial jolt. The switch is located in the passenger's footwell, in the right upper corner. For more information, refer to the Roadside Emergencies chapter in your Owner's Guide.

Roadside Assistance – Your new Lincoln MKZ comes with the assurance and support of 24-hour emergency roadside assistance. Roadside assistance includes such services as: lockout assistance, limited fuel delivery, battery jump starts, changing a flat tire, towing and winch out.

To receive roadside assistance in the United States, call **1 (800) 241-3673**. In Canada, call **1 (800) 665-2006**. For more information on coverage period and details of service, refer to your Roadside Assistance Information card.

SecuriLock™

The SecuriLock™ passive anti-theft system is an engine immobilization system. This system is designed to help prevent the engine from being started unless a coded Integrated Keyhead Transmitter (IKT) programmed to your vehicle is used. Using the wrong type of coded key may lead to a "no start" condition. The anti-theft indicator (L) (if equipped) in the instrument cluster will flash to indicate the SecuriLock system is functioning as a theft deterrent when the ignition is turned off.

Reverse Sensing (if equipped)

Your vehicle may be equipped with a reverse sensing system which can warn you if there

is an object behind the vehicle. The system will sound a warning tone that increases in frequency as the object gets closer and will sound continuously when the object is less than 10 inches away. Refer to your Owner's Guide for safety information and more details.

All Wheel Drive (AWD) (if equipped)

Your vehicle may be equipped with All Wheel Drive (AWD). AWD uses all four wheels to power the vehicle, thereby increasing traction and enabling you to drive over terrain and road conditions that a conventional two-wheel drive vehicle cannot. **Note:** If your vehicle is equipped with AWD, a spare tire of a different size (other than the tire provided) should never be used. Using a different size could cause the AWD system to stop functioning and default to front wheel drive. Your vehicle is not intended for off-road use.

Rear Seat Release

Both rear seats can be folded down for additional cargo space. Pull the release handle located inside the trunk to fold down the seat.

Moon Roof (if equipped)

The moon roof is equipped with a one-touch express opening/closing and venting feature. To open the moon roof, press and release the rear portion of the control. To close the moon roof, press and release the front portion of the control when the glass panel is closed. To stop motion at any time during the one-touch operation, press the control a second time.

Global Open Front Windows (if equipped)

You can open your front windows and moon roof (if equipped) simultaneously using your Integrated Keyhead Transmitter (IKT). Press and hold (L) until the two front windows and moon roof begin to open. If any other remote entry transmitter control is pressed during the opening operation, both windows and the moon roof will stop opening.

SYNC (if equipped)

Your vehicle may be equipped with SYNC – a hands-free communications and entertainment system with special phone and media features. For more information, please refer to the SYNC Supplement or to the SYNC section in the Navigation Supplement. Please also feel free to visit www.SyncMyRide.com.

Audio System

In-Dash Six CD/MP3 THX II Satellite Compatible Sound System (if equipped)

THX® II (if equipped)

Your vehicle may be equipped with the THX II certified premium audio system. This system creates optimal acoustic quality for all seating positions and road conditions. The system offers an advanced speaker system, amplifiers, subwoofer and equalization.

1. Load

– Press LOAD and a memory preset to load to a specific slot. Press and hold to auto load up to six CDs.

2. ON/OFF/Volume

Press to turn ON/OFF. Turn to increase/decrease volume. If the volume is set above a certain level and the ignition is turned off, the volume will come back on at a "nominal" listening level when the ignition switch is turned back on.

SATELLITE RADIO CONTROLS (if equipped)

3. AUX – Press repeatedly to cycle through SAT1, SAT2, SAT3 (satellite radio mode if equipped), LINE IN (auxiliary audio mode) or SYNC (if equipped). Satellite radio is available only with a SIRIUS radio subscription. Check with your authorized dealer for availability. If your vehicle is equipped with SYNC, please refer to the SYNC supplement for further information. Once Satellite Radio mode is activated you may use the following functions:

Press MENU when satellite radio mode is active to access. Press OK to enter into the SATELLITE RADIO MENU. Press (L) to cycle through the following options: CATEGORY, SAVE SONG, DELETE SONG, DELETE ALL SONGS, ENABLE ALERTS/DISABLE ALERTS.

4. SHUFFLE

– Press to play all tracks on the current CD/MP3 disc in random order.

5. SEEK

– Press to access the previous/next strong station or CD track.

6. TEXT/SCAN

– In radio mode, when listening to a RBDS-equipped station, press and release to view the text information of the radio station, if available. Press and hold for a brief sampling of radio stations. In CD/MP3 mode, press and release to view the track title, artist name, disc title or file name, if available. Press and hold for a brief sampling of all tracks on the current disc.

7. (PLAY/PAUSE) & OK

PLAY/PAUSE – In CD/MP3 mode, press to pause the playing media. PAUSE will appear in the display. Press again to return to the playing media.

OK – Use in various menu selections. Your vehicle may be equipped with SYNC. For more information, refer to the SYNC supplement.

8. MENU

– Press repeatedly to cycle through:

Autoset – Allows you to set the strongest local radio stations without losing your original stored stations in AM/FM1/FM2. Use (L) to turn on/off. When the six strongest stations are filled, the station stored in preset 1 will begin playing. If there are less than six strong stations, the system will store the last one in the remaining presets.

Occupancy mode, if equipped – Use (L) to select and optimize sound for ALL SEATS, DRIVERS SEAT or REAR SEATS.

Speed sensitive volume Radio volume automatically changes slightly with vehicle speed to compensate for road and wind noise. Recommended level is 1-3. Level 0 turns the feature off and level 7 is the maximum setting.

RBDS (Radio Broadcast Data System) – In FM mode, this feature allows you to search for certain categories of music or announcements. For more information, refer to your Owner's Guide.

9. Tune – Turn to go up/down the frequency band in individual increments, or to advance to the next/previous MP3 folder.

– If your vehicle is equipped with SYNC, press to access SYNC PHONE features. For further information please refer to your SYNC supplement for further information. If your vehicle is not equipped with SYNC, the display will read NO PHONE.

Auxiliary Input Jack – Your vehicle is equipped with an auxiliary input jack which allows you to play audio from a portable music player through the vehicle speakers. To use, plug your portable player into the input jack located inside the center console. Turn the radio on and adjust the volume to a comfortable level. Turn on your portable music player and adjust to approximately 1/2 volume. Press AUX on your audio system repeatedly until LINE IN appears in the display. Adjust the volume as needed. Refer to your Owner's Guide for more information. If your vehicle is equipped with a navigation system, refer to your navigation supplement for information on accessing this mode.



Climate System

Dual Automatic Temperature Control (DATC) System with Heated and Cooled Seats (if equipped)

1. Temperature Controls

Press the driver side controls to increase/decrease the temperature in the vehicle cabin (single zone). Press the passenger side controls to activate dual zone and allow the driver and passenger to control their individual settings.

2. Fan Speed

– Press to manually increase or decrease the fan speed. To return to automatic fan operation, press AUTO.

3. AUTO

– Press to activate automatic temperature control. The system will automatically determine fan speed, airflow location, A/C on or off and outside or recirculated air, to heat or cool the vehicle to reach the desired temperature. Press again to deactivate.

4. Driver/Passenger Cooled Seats (if equipped)

Press to activate. Press once for full cool (three lights), twice for medium cool (two lights) and a third time (one light) for low cool. Press again to deactivate (no lights).

5. OFF

– Outside air is shut out and the fan will not operate.

6. Driver/Passenger Heated Seats

– Press to activate. Press once for full heat (three lights), twice for medium heat (two lights) and a third time (one light) for low heat. Press again to deactivate (no lights).

7. EXT

– Press to display the outside air temperature. Press again to display cabin temperature settings.

8. Airflow Direction Control

Press repeatedly to cycle through the available air distribution modes. The selected mode will appear in the display. To return to full automatic control, press AUTO.

9. Recirculation Control

Used to manually enable or disable recirculated air operation. When activated, recirculates air in the cabin thereby reducing the amount of time to cool the interior of the vehicle. May also help reduce undesired odors from reaching the interior of the vehicle. Will work in all modes except defrost.

10. Rear Window Defroster

Press to clear the rear window and the outside rearview mirrors of thin ice and fog. Press again to deactivate. The defroster will turn off automatically after 10 minutes.

11. Defrost

– Press to distribute outside air through the windshield defroster and demister vents. Can be used to clear thin ice or fog from the windshield.

12. DUAL Zone Selector

Press to activate dual zone mode where the driver and passenger individually control their temperature settings. Press again to return to single zone mode where the driver's settings determine the cabin temperature.

For Maximum Cooling Performance

Press (L), A/C, (L) and set the temperature to 60° F (16° C) and the highest blower setting.



MKZ 2009
Quick Reference Guide

MKZ²⁰⁰⁹

Quick Reference Guide

Sleek. Dynamic. Stylish. The Lincoln MKZ awaits you. From the luxurious amenities to the quiet interior, Lincoln's classic touch ensures that every drive is a unique and comforting one. Experience your own private sanctuary as the spirited engine carries you effortlessly through the next curve, the MP3 sound system sets the pace with your favorite music, and the luxurious leather seats unfold you. You may never want to leave.

Take a few minutes to use this Quick Reference Guide to acquaint you with any of the features you'll use most. For more detailed information, and important safety information, refer to your Owner's Guide.

Use extreme caution when using any device or feature that may take your attention off the road. Your primary responsibility is the safe operation of the vehicle. Only use non-essential features and devices when it is safe to do so.




1 2 3 2 4 5 6 7 8 9 10 11 12 13 14

Cockpit

Quick Reference Guide


.1 Headlamps, Fog Lamps and Panel Dimmer Control

Turn the control one position to the right to turn on the parking lamps, instrument panel lamps, license plate lamps and tail lamps. Turn the control to the second position on the right to turn on the headlamps. Turn the control one position to the left to activate the autolamp feature, which automatically turns the exterior lamps on and off, based on available daylight. The system also keeps the lights on for a short time after the ignition switch is turned to the LOCK (OFF) position. Pull the control out to activate the fog lamps. The fog lamp indicator light will illuminate. The fog lamps will not operate when the control is turned off (O) or when the high beams are on. Use the panel dimmer control to adjust the level of brightness on the instrument panel during parking lamp and headlamp operation. Move the control to the full upright position, past the detent, to turn on the interior lamps.




.2 Steering Wheel Controls

The appearance and functionality of your vehicle's steering wheel controls may vary according to your option package. Refer to your Owner's Guide for a complete description of all possible options. To set the speed control, press and release ON. Accelerate to the desired speed. Press and release the SET (+) control. Take your foot off the accelerator pedal. The speed control indicator light will illuminate in the cluster. To set a higher speed: press and hold SET (+) until the desired speed is reached, or briefly press SET (+) to increase the speed by small amounts. To set a lower speed: press and hold SET (-) until the desired speed is reached, or briefly press SET (-) to decrease the speed by small amounts. Press RESUME to return to the previously set speed. To turn speed control off, depress the brake pedal or press OFF. Press to access the previous/next preset radio station, CD track or preset



.3 Tilt/Telescopic Steering Wheel

Push the lever down to unlock the steering column. Move the steering wheel up or down and in or out to find the desired position. While holding the steering wheel in place, pull the lever up to lock the steering column.




.4 Message Center

The message center displays important vehicle information through a constant monitoring of vehicle systems. The message center also provides vehicle system checks and will notify you of potential vehicle problems with a display of




.5 In-Dash Clock

Press + to advance the time. Press - to reverse the time.



.6 AdvanceTrac® (if equipped)

The AdvanceTrac® stability enhancement system helps avoid wheel spin and loss



.7 Passenger Airbag Off

Your vehicle has a safety feature which automatically knows when to engage or disengage the passenger airbag. When the system senses no weight or light to medium weight (such as a heavy binder or suitcase), in the front passenger seat, the PASS AIRBAG OFF indicator lamp will illuminate, signifying the passenger airbag is not engaged. Refer



.8 Traction Control™ Light

This light illuminates when the Traction Control™ is active. If the light remains on, have the system serviced immediately by an authorized dealer.



.9 Throttle Control/Transmission Light

This light illuminates when a powertrain or AWD (if equipped) fault has been detected. Contact an authorized dealer as soon as possible to have your vehicle serviced.




.10 Service Engine Soon Light

The Service Engine Soon light illuminates briefly when the ignition is turned on. If it remains on or is blinking after the engine is started, the On Board Diagnostics System (OBD-II) has detected a malfunction. Drive in a moderate fashion and have your vehicle




.11 Airbag Readiness Light

The Airbag Readiness light illuminates briefly when the ignition is turned on. If this light remains on or continues to flash after the engine is started, have the system serviced immediately by your authorized dealer. A chime will sound if a malfunction in the supplemental restraint system is detected as well.




.12 Anti-Lock Brake System (ABS)

The ABS light illuminates briefly when the ignition is turned on. If the ABS light remains on or flashes after the engine is started, have the system serviced immediately by your authorized dealer. Normal braking (less ABS) will still be functional unless the brake system warning light is also illuminated. **Note:** It is normal to feel a pedal pulsation or hear a slight noise when the ABS system is activated.



.13 Brake System Warning Light

The brake system warning light illuminates briefly when the ignition is turned on. If this light remains on after releasing the parking brake, this indicates a low brake fluid level or a brake system malfunction. Have the brake system inspected immediately by an authorized dealer.



.14 Check Fuel Cap Light

This icon illuminates when the fuel cap may not be properly installed. If you continue to drive with this light illuminated, the Service Engine Soon indicator light may come on.



Auxiliary Power Point


The auxiliary power point is located in the utility compartment in the center console. **Note:** Do not use the power point over the capacity of 12VDC/180W.

USB PORT (if equipped)

Your vehicle is equipped with a USB port inside your center console. This feature allows you to plug in media playing devices, memory sticks, and also to charge devices (if supported). For more detailed information, please refer to the SYNC supplement or the SYNC section of the Navigation supplement.


Glove Box CD Storage

Your vehicle is equipped with a special area for your CD storage. It is located inside the glove box, to the right of the main bin.



HomeLink® (if equipped)

Located on the driver's visor, the HomeLink® Wireless Control System is a convenient way to replace up to three hand-held transmitters with a single built-in device. This system learns the



radio frequency codes of most transmitters to operate garage doors, entry gates, security systems, entry door locks, and home or office lighting. Refer to your Owner's Guide for more information.

