



Application for iPhone/iPod touch/iPad

Disklavier Controller

User's Guide

Disklavier Mark IV Series

Disklavier E3

Disklavier Control Unit DKC-850

Introduction

Thank you for downloading the Disklavier Controller!

This exciting application allows you to control many of the basic functions of your Disklavier Mark IV, Disklavier E3 or Disklavier Control Unit DKC-850. Please read this guide before operating this application.

Compatible devices (as of September 1, 2010)

This application is compatible with the following Apple products (iOS 3.0 or later is required).

- iPhone
- iPod touch
- iPad

Requirements

- The firmware of your Disklavier must be as follows. Refer to the Disklavier operating manual and update the firmware.
 - For Disklavier Mark IV : Version 4.00 or later
 - For Disklavier E3 : Version 3.00 or later
 - For Disklavier Control Unit DKC-850 : Version 3.10 or later
- Your iPhone/iPod touch/iPad must be connected to the Disklavier through a wireless router.




Table of Contents

Chapter 1 Getting Started

- 2 Screen Menu Structure
- 3 Starting the Application
- 4 Searching for a Piano
- 5 Connecting to a Piano
- 6 Entering Your Passcode
- 7 Putting the Disklavier in Standby Mode
- 8 Reactivating from Standby Mode

Chapter 2 Song Playback

- 10 Selecting a Song
- 13 Operation during Playback

Chapter 3 DisklavierRadio Playback

- 16 Selecting a Channel
- 18 Operation during DisklavierRadio Playback

Chapter 4 Recording Songs

- 20 Starting Recording
- 21 Stopping Recording
- 22 Titling a Song

Chapter 5 Other Functions

- 24 Adjusting Sound Source Volume Balance
- 25 Transposing Songs
- 26 Changing Song Tempo
- 27 Cancelling Parts
- 28 Using Shortcuts

Chapter 6 Related Information


- 30 Notes on the Passcode Setting
- 31 Troubleshooting
- 32 Trademarks and Copyrights

1

Getting Started

Screen Menu Structure

The following is an approximate representation of the screen menus.



* This screen appears when connecting to a piano with the passcode set.

Starting the Application

Tap on [the application icon](#).



The opening screen appears.



When you have previously connected to a piano:

The application connects to that piano automatically.

 [Operation during playback \(page 13\)](#)

When connecting to a piano for the first time:

The application searches for a piano.

 [Searching for a piano \(page 4\)](#)

Searching for a Piano

When connecting to a piano for the first time, you must first find the piano to which you want to connect.

Tap on [Piano Search].



Language switch

Switches the language displayed in this screen between English and Japanese.

[Piano Search]

Starts searching for pianos.


Once the search is complete, select the piano to which you want to connect.

 [Connecting to a piano \(page 5\)](#)

Connecting to a Piano

A list of pianos the application found appears.
Select from the list the piano to which you wish to connect.

Tap on the piano you wish to connect to.



Piano list

[Demo Mode]*

Switches to the demonstration mode, in which you can check the operations on the Disklavier Controller even when no pianos are found.

* Operations in demonstration mode are the same as those when connected to the Disklavier Mark IV.

After completion, perform passcode authentication if required.

- 🔑 Entering your passcode (page 6)
- 🔑 Setting the passcode (page 30)


Otherwise, start song playback.

- 🔊 Operation during playback (page 13)

Entering Your Passcode

After connection is complete, carry out authentication by entering your 4-digit passcode. Enter the passcode you set on the Disklavier.

Enter 4-digit passcode and tap on [OK].



Putting the Disklavier in Standby Mode

Tap on [\[More\]](#) in the toolbar, then on [\[Standby\]](#) in the [More](#) screen that appears.




To reactivate your Disklavier...

[➡ Reactivating from Standby Mode \(page 8\)](#)

Reactivating from Standby Mode

Use the following screen to reactivate your Disklavier from Standby mode.

Slide [the switch](#) to the right.



Switch
Reactivates your Disklavier from Standby mode.

Song Playback

Selecting a Song

Tap on [Select] in the toolbar.



Tap on the desired source/media.



Mark IV

Source list



E3 DKG-850


Media list

Next, select an album.

[Selecting an album \(page 11\)](#)

Selecting a Song (continued)


Tap on the desired album.



[Source]

Returns to source selection.

Album list



[Media]

Returns to media selection.

Album list

Next, select a song.

[Selecting a song \(page 12\)](#)

Selecting a Song (continued)

Tap on the desired song.




Mark IV

[Album]

Returns to album selection.

Song list



DKG-850

[Album]

Returns to album selection.

Song list*

* Displaying the list may take time if there are many songs.


The selected song is played back.

Operation during playback (page 13)

Operation during Playback

Tapping on the screen during song playback shows the song control panel for various operations.* Display of the song control panel cycles on and off every time you tap on the screen.

Tap on the screen during playback.



Song title

[>>>] (skip / fast forward)

Skips to the next song when tapped briefly (less than one second).

Fast-forwards through the current song when tapped for a longer period (at least 1 second).

[▶] (play / pause)

Starts or pauses playback.

Song position

Displays the playback position.

[<<<] (skip back / rewind)


Skips to the previous song when tapped briefly (less than one second).

Rewinds through the current song when tapped for a longer period (at least one second).

* Operations in this application may not always take effect on your Disklavier immediately.

Operation during Playback (continued)

Tap on the screen during playback.



Repeat mode

Cycles through the repeat mode.

- : Repeat off
- : Single repeat mode
- : All repeat mode
- : Random repeat mode

Main volume

Adjusts the main volume.

Quiet status^{*1}

Cycles through the quiet status.

- : Acoustic mode
- : Quiet mode
- : Headphone mode^{*2}

^{*1} You cannot change quiet status when connected to some models of the Disklavier E3 and Disklavier Control Unit DKC-850.

^{*2} For Disklavier E3 upright pianos and Disklavier Control Unit DKC-850, this does not appear. For Disklavier E3 grand pianos and Disklavier Mark IV, the quiet status is locked to Headphone mode when you connect headphones.


DisklavierRadio Playback

Selecting a Channel

Tap on [Select] in the toolbar.



Tap on [DisklavierRadio] or [D-Radio].




Next, select a channel.

 [Selecting a channel \(page 17\)](#)

Selecting a Channel (continued)

Tap on the desired channel.




[Source]

Returns to source selection.

Channel list*

* To select channels other than the two complimentary channels, you must first log into the Internet Direct Connection (IDC) service on the Disklavier.



[Media]

Returns to media selection.

Channel list*

* To select channels other than the two complimentary channels, you must first log into the Internet Direct Connection (IDC) service on the Disklavier.

The selected channel is played back.

➡ Operation during playback (page 18)

Operation during DisklavierRadio Playback

Tapping on the screen during DisklavierRadio playback shows the song control panel for various operations.*¹ Display of the song control panel cycles on and off every time you tap on the screen.

Tap on the screen during playback.



Channel title / song title

[Mute Off] / [Mute On]

Cycles the mute function on and off.

Main volume

Adjusts the main volume.

[Back]

Returns to channel selection.

Quiet status*²

Cycles through the quiet status.

 : Acoustic mode

 : Quiet mode

 : Headphone mode*³

*¹ Operations in this application may not always take effect on your Disklavier immediately.

*² You cannot change quiet status when connected to some models of the Disklavier E3 and Disklavier Control Unit DKC-850.

*³ For Disklavier E3 upright pianos and Disklavier Control Unit DKC-850, this does not appear. For Disklavier E3 grand pianos and Disklavier Mark IV, the quiet status is locked to Headphone mode when you connect headphones.


Recording Songs

Starting Recording

Tap on [More] in the toolbar, then on [Record] in the More screen that appears.



Tap on [Rec Start] and play the Disklavier.




Recording will start by playing the Disklavier, and the counter starts to advance.

[▶ Stopping recording \(page 21\)](#)

Stopping Recording

Tap on [\[Stop\]](#).



[\[Stop\]](#)
Stops recording.


Next, title the song you have just recorded.

 [Titling the recorded song \(page 22\)](#)

Titling a Song

After recording the song, you can add a title to that song.
We recommend entering titles in alphanumeric characters. Non-alphanumeric characters in titles may not be displayed correctly on your Disklavier.


Enter [a title to the recorded song](#) and tap on [\[OK\]](#).




Other Functions

Adjusting Sound Source Volume Balance

Tap on [Balance] in the toolbar.



Use the slider to adjust the volume for each sound source.



[Voice]

Adjusts the volume of the piano part.

[TG]


Adjusts the volume of the ensemble part from the internal tone generator.

[Audio]

Adjusts the volume of software (audio CD, etc).

[Mic]

Adjusts the microphone level.



[Voice]

Adjusts the volume of the piano part.

[TG]

Adjusts the volume of the ensemble part from the internal tone generator.

[Audio]

Adjusts the volume of software (audio CD, etc).

Transposing Songs

Tap on [More] in the toolbar, then on [Play Function] in the More screen that appears.



Use [Transpose ◀] / [Transpose ▶] to transpose.



[Transpose ◀] / [Transpose ▶]
Adjusts the key in half steps, 24 half-steps lower or higher (i.e. 2 octaves in either direction).

Changing Song Tempo

Tap on [More] in the toolbar, then on [Play Function] in the More screen that appears.



Use the slider to adjust the tempo.



[Tempo]

Adjusts the tempo over the following range:
Disklavier Mark IV: -50% to +20%
Disklavier E3: -50% to +50%

[Reset]

Returns to the default tempo (0%).

Cancelling Parts

Tap on [\[More\]](#) in the toolbar, then on [\[Play Function\]](#) in the [More](#) screen that appears.



Use [\[Part Cancel\]](#) to switch parts on and off.




[\[Part Cancel\]](#)
Switches the left (L) or right (R) parts on and off.

Using Shortcuts

Tap on [More] in the toolbar, then on [Short Cut] in the More screen that appears.



Tap on the desired shortcut.



* Shortcuts can only be assigned, edited or deleted on the Disklavier.

Related Information

Notes on the Passcode Setting

To prevent others from controlling your Disklavier with the Disklavier Controller, you can set the passcode on your Disklavier.

Default setting


No passcode is set as default, which means any Disklavier Controller can control your Disklavier.

How to set the passcode

The passcode can be set in the passcode setting screen of your Disklavier.


For Disklavier Mark IV users:

You can access this screen by tapping on , then on . Refer to the Advanced Operating Manual for more information.



For Disklavier E3 and Disklavier Control Unit DKC-850 users:

You can access this screen by pressing [SETUP] on the remote control, then selecting "Passcode." Refer to the Operation Manual for more information.



Set the 4-digit number as the passcode.

You can control your Disklavier with the Disklavier Controller by entering the passcode set in this screen (see page 6).

Forgot passcode?

Delete or reset the passcode in the screen above.

Troubleshooting

If you have problems operating the Disklavier, see if any of the symptoms listed below apply to your problem and follow the recommended remedy.

The Disklavier Controller does not function at all.

- ♪ Your iPhone/iPod touch/iPad and the Disklavier may not be connected in a wireless environment. Make sure that your iPhone/iPod touch/iPad is connected to a WiFi access point that is on the same network as your Disklavier for this application to function.
- ♪ The firmware of your Disklavier must be as follows. Check the version of firmware you are using and update the firmware if necessary.
 - For Disklavier Mark IV : Version 4.00 or later
 - For Disklavier E3 : Version 3.00 or later
 - For Disklavier Control Unit DKC-850 : Version 3.10 or later

You cannot find or connect to the desired piano.

- ♪ You may be using the iPhone/iPod touch/iPad too far from the wireless router to which your Disklavier is connected. Make sure that your iPhone/iPod touch/iPad is within the specified communication range.

The Disklavier Controller does not respond even when you tap on the buttons.

- ♪ Restart your iPhone/iPod touch/iPad.
- ♪ Uninstall the Disklavier Controller from your iPhone/iPod touch/iPad, and then reinstall it.

Trademarks and Copyrights

- Yamaha and Disklavier are trademarks of Yamaha Corporation.
- Apple, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. iPad is a trademark of Apple Inc.

