



DON'T
PANIC
viaGPS 4.0

USERMANUAL

A Turn-by-turn Navigation System for GPS Devices by



Mireo DON'T PANIC User Manual

Copyright © 2011, Mireo d.d.

All rights reserved. No part of this document may be disclosed to third parties, translated, copied, or duplicated in any form, in whole or in part, or by any means electronic, mechanical, photocopying, recording or otherwise without the express prior written permission of Mireo d.d.

Disclaimer

Every reasonable effort has been made to make this manual as complete and accurate as possible. This manual should be considered "as is" and neither Mireo nor its employees, officers or directors shall be responsible or incidental for consequential damages resulting from the use of this material or liable for technical or editorial omissions made herein.

Illustrations provided by Gestureworks (www.gestureworks.com)

Table of Contents

Introduction	1
Shorthand	2
Tappable Items.....	2
Arrows.....	2
Quick Start: Simple Search and Navigation	3
Finding and Navigating to a Destination	3
Part 1: Getting Started	4
Touch Gestures	5
Using Touch Gestures in Map View.....	5
Selecting an Item.....	5
Panning the Map.....	5
Tilting the Map.....	5
Rotating the Map.....	6
Zooming In/Out.....	6
Selecting a Point on the Map.....	7



Using Touch Gestures in Menu Pages.....	7
Selecting, Deselecting and Toggling an Item.....	7
Scrolling a Page	8
The Map View.....	9
The Control Bar	9
The Search Button.....	10
The Driving Options Button.....	10
The Last Page Accessed Field / Map View Button.....	10
The Main Menu Button	11
The Status Bar.....	11
The GPS Signal Strength Indicator	11
The Current Speed indicator	11
The Clock Display	11
The Battery Level Indicator.....	11
The Smart Orientation Button and Menu.....	12
The Rotation Mode Button.....	12
The Panning Mode Button.....	12
The 2D Mode Button	12
The 3D Mode Button	12
The Show North Button	12
The Select Place On Map Button.....	12
The Smart Zoom Button and Multi-zoom Menu.....	13
The Block View / View Preset 1 Button*	13
The Area View / View Preset 2 Button*	13
The City View / View Preset 3 Button*	13
The Auto Zoom Button.....	14
Map View Location Icons and Buttons	14
Your Current Location Icon	14
The No GPS Signal Location	14
Your Current Location Finder Button.....	15
The Start Point Icon.....	15
The Start Point Name Button.....	15
The Destination Icon	15
The Destination Name Button	15
The Via Point Icon	16
The Via Point Name Button	16
Additional Via Points Icon	16
The Map Selection Point Icon	16
The Map Selection Point Name Button	16



The Favorite Place Point Icon	17
The Favorite Place Point Name Button	17
The Search Result Point Icon	17
The Search Result Name Point Button	18
Page View Buttons and Icons	18
The Active Route Icon	18
The Inactive Route Icon	19
The Pause/Resume/Record Route Button	19
The Favorite Place / Priority Favorite Place Button	19
The Map Locator Button	20
The Home Icon	20
Part 2: Using the Application	21
Using Search	21
Defining Search Categories	22
Selecting a Country Map	23
Using the Keyboard Toggle Button	23
Using the Letter/Number/Symbol Toggle Button	24
Using the What Field	24
Using the Where Field	24
How to Delete a Single Space	25
How to Clear the Search Fields	25
How to Get a Complete List of Search Results	25
How to Narrow Your Search Results and View Their Details	26
How to See a Search Result in Map View	26
How to Reveal the Keyboard	27



How to Use the Location Details / Route Planning and Options Page	27
You Can Get to this Page in a Number of Ways	27
Using the Location Details Bar	28
Using the Route Planning Bar.....	28
Using the Via Point Order Bar.....	29
Using the Place Bar	30
Getting out of this Page.....	32
Creating Smart Zoom Menu Presets	32
Restoring Defaults	33
Using the Main Menu	34
How to Get to the Main Menu and Where I Can Go from There.	34
Using Take Me Home.....	34
Using Route Options.....	35
Getting to the Trip, Dashboard and Directions Page.....	36
Using the Current Trip Status and Control Bar	36
Using the Current Route Details Display Bar	37
Using the Route Planning Bar	38
Using the Via Point Order Bar.....	39
Using the Place Bar	40
Using the Route Options Bar.....	42
Reading the Dashboard	43
Using Directions	44
Using Favorites.....	45
Creating a Favorite Place	45
Creating a Favorite Route	46
Getting to the Favorite Places and Favorite Routes Pages.....	46
Using Favorite Places.....	46
Using Favorite Routes	47



Using History.....	49
Getting to the Destinations and Trip Log Pages	49
Using Destinations.....	49
Using the Trip Log.....	50
Creating Settings.....	51
Getting to the Settings and About Page	51
Using the Settings Page.....	52
Selecting Your Language.....	52
Selecting Your Voice.....	52
Selecting You Distance and Speed Units	52
Selecting Additional Keyboards.....	53
Restoring the Factory Settings	53
Using the About Page.....	53
About	53
Check for Updates and Recover Content.....	54
Using the Store.....	54
Buying Additional Content	54
The Downloads Page	55



Introduction

First things first: thanks for buying Mireo DON'T PANIC. We appreciate your business and commend you on your choice. We put a lot of thought and effort into making a great smart phone navigation app, and you immediately recognized it as the masterpiece that it is... or you just saw the price tag and said, "Wow! That's super cheap for an on-board, turn-by-turn navigation app! Gimme! Gimme!" Either way, you're here now, reading the user manual to figure out how to use the app. So, without further ado, let's get started!



Shorthand

Tappable Items

Tappable items will appear in **red** throughout the manual.

Arrows →


Take Me Home → **Cancel Current Route** → **Yes**. You'll see sentences like these in Part 2 of the User Manual. This shortened formulation represents much lengthier instructions that tell you to open multiple nested screens in sequence, i.e., "Tap the **Take Me Home** button. On the following screen, tap **Cancel Current Route**. On the screen after that, tap **Yes**."

Quick Start

Simple Search and Navigation

You've downloaded and started the app and want to get to a certain address. Here's a quick, super-basic way to start navigating immediately.

Finding and Navigating to a Destination



Part 1

Getting Started

Or: What the Heck Do All These Icons, Buttons and Fields Mean?

At this point you've probably already opened the app, eagerly tapped several buttons and are now staring blankly at a bunch of unfamiliar icons. Relax. This is the part where we show you what all the nifty little buttons, icons, bars and fields mean. We'll also go through and define some basic terminology (with pictures!) to make things easier to understand.


Touch Gestures

Using Touch Gestures in Map View

Use your fingers to manipulate the map and page views in the app.




Selecting an Item: Tap the screen surface once with a fingertip to select a button on the Control Bar, a map icon, etc.



Panning the Map: Move or quickly brush your fingertip across the screen surface to pan across the map.




The Inertia Pan feature enables your pan come to a smooth, gradual stop as opposed to an unnatural abrupt one.



Tilting the Map: Touch the screen surface with two fingers and move them up and down at the same time (vertically) to tilt the map view between a 3D and 2D map view.



The map view automatically "snaps to 2D" when you have tilted close to the 2D aerial view.




Rotating the Map: Touch the surface with two fingers and move them in a clockwise or counterclockwise direction to rotate the map view.



You can pinch or spread your fingers to zoom in or out as you rotate.



The map view automatically "snaps to north" when you have rotated close to a north view.




Zooming In/Out: Pinch or spread your fingers on the screen to zoom in or out of the map.



You can move your fingers in a clockwise or counterclockwise direction to rotate as you zoom.



Tap repeatedly with a single finger to zoom in incrementally.



Selecting a Point on the Map: Touch and continue pressing a point on the map with a fingertip to select it. A **Map Selection Point** icon will appear on that spot.




Pressing a point on the map with your finger on a Personal Navigation Device (PND) will zoom in the view.

Using Touch Gestures in Menu Pages



Selecting, Deselecting and Toggling an Item: Tap the screen surface once with a fingertip to select a button, tab, list, deselect or toggle an applicable item.



Scrolling a Page: Move or quickly brush your fingertip up and down the screen surface to scroll up and down a page.




The Inertia Pan feature enables your scroll to come to a smooth, gradual stop as opposed to an unnatural abrupt one.

The Map View


This is the first screen you'll see once the app starts. Your smart phone's GPS (Make sure it's switched on and working!) will tell the app where you're at and you'll see your location. This is the app's default start screen and it's called Map View.

The Control Bar



Located along the bottom of your screen in Portrait mode, the Control Bar features the **Search** button, the **Driving Options** button, the **Last Page**

Accessed field, the **Main Menu** button. In Landscape mode it is combined with the Status Bar and features the GPS Signal Strength indicator, the Current Speed indicator, the Clock display and the Battery Level indicator as well.



Q The Search Button. Tapping the **Search** button takes you immediately to the Search page. The **Search** button is always present on the Control Bar no matter where you are in the app. Tap it from anywhere in the app to go directly to the Search page. You can instantly return to the Map View by tapping the **Close** tab in the upper right-hand corner of the Search page in portrait mode or **Cancel** in the far, lower left-hand corner of the Search Page when you're in Landscape mode.

📍 The Driving Options Button. Tapping the **Driving Options** button takes you to the Driving Options page where you can choose your Alert options: **Speed Alert**, **Safety Camera Alert**, **POI (Points Of Interest) Along The Route** and **TMC Traffic Alerts**. Scroll down to the bottom of the page to the **Map Display** button. Tapping on it takes you to the Select Map Display page where you can choose the **Day**, **Night** or **Automatic** display modes. Tapping the **Close** tab in the upper right-hand corner returns you to the Map View.



The Last Page Accessed Field / Map View Button. This field displays the tappable menu category button of the last Main Menu category page you accessed. Tapping it will take you to that menu category page. When you are in a Main Menu category page, the Last Page Accessed field switches the **Map View** button which takes you instantly back to your previous Map View.





This is a great tool for toggling quickly between the current Main Menu page and Map View.

- **The Main Menu Button.** Tap the **Main Menu** button to access the Main Menu page where you can access the **Take Me Home, Route Options, Favorites, History, Settings** and **Store** buttons. Return to the Map View by tapping the **Map View** button on the Control Bar or exit the application completely by tapping the **Exit Application** button on the Control Bar.


The Status Bar

The Status Bar is located along the top of your screen in portrait mode. It features the GPS Signal Strength indicator, the Current Speed indicator, the Clock display and the Battery Level indicator. In Landscape mode, it's combined with the Control Bar along the bottom of the screen.





-  **The GPS Signal Strength Indicator.** This displays your smart phone's or PND's GPS signal strength. Three yellow bars indicate the maximum GPS signal strength (within a 5 meter accuracy). Fewer yellow bars indicate a progressively weaker, less accurate, GPS signal. Three red bars indicate the absence of a usable GPS signal.




- The Current Speed indicator.** This icon indicates your vehicle's current speed.







- The Clock Display.** This one shows you the current time.

-  **The Battery Level Indicator.** It lets you know your smart phone's current battery level. An electrical plug inside the icon () indicates that the battery is being charged. A lightning bolt inside it () lets you know the battery is fully charged. A red battery icon () warns you that you're nearly empty. A completely dark screen probably means you forgot to charge your battery last night!

The Smart Orientation Button and Menu




Tap the **Smart Orientation Menu** button once to access the Smart Orientation menu.

-  **The Rotation Mode Button.** Tap the **Smart Orientation Menu** button once to access the Smart Orientation menu. Tap the **Rotation Mode** button to toggle between Panning and Rotation modes.
-  **The Panning Mode Button.** Tap the **Smart Orientation Menu** button once to access the Smart Orientation menu. Tap the **Panning Mode** button to toggle between Panning and Rotation modes.
- 2D** **The 2D Mode Button.** Tap the **Smart Orientation Menu** button once to access the Smart Orientation menu. Tap the **2D** button once to toggle between a two-dimensional (aerial) map view and a three-dimensional (depth-perspective) map view.
- 3D** **The 3D Mode Button.** Tap the **Smart Orientation Menu** button once to access the Smart Orientation menu. Tap the **3D** button once to toggle between a three-dimensional (depth-perspective) map view and a two-dimensional (aerial) map view.
-  **The Show North Button.** Tap the **Smart Orientation Menu** button once to access the Smart Orientation menu. Tap the **Show North** button to instantly rotate your map view so that north is at the top of your screen.
-  **The Select Place On Map Button.** Tap the **Smart Orientation Menu** button once to access the Smart Orientation menu. Tap the **Select Place On Map** button, then press and hold any point on the map. A street address, street name or GPS coordinates will appear in the **Map Selction Point Name** button. Tap on the **Map Selction Point Name** button to view its Details / Route Planning and Options Page

where you can view the locations full information, navigate to it, add it as a destination, set it as your start point, find the closest point of interest, add it to your favorites or set it as home. Close the Details / Route Planning and Options Page by tapping the **Close** tab.

The Smart Zoom Button and Multi-zoom Menu



In the Map View mode, tap the **Smart Zoom** button once to access the basic Zoom In / Zoom Out function. Tap or continuously press the **Plus** button to zoom in for a more detailed map view. Tap or continuously press the **Minus** button to zoom out for a wider map view. Tap on the **Smart Zoom** button again to access the Multi-zoom menu.

Tap on the **Smart Zoom** button twice to access the Multi-zoom menu.

- **The Block View / View Preset 1 Button***. Once you're inside the Multi-zoom menu, tap on the **Block View / View Preset 1** button to instantly switch the current map view of your present GPS location to an even closer 3D view of a block within a city, town or village around your GPS location. All street names are displayed. Tap the **Smart Zoom** button twice to return to the Multi-zoom menu.
- **The Area View / View Preset 2 Button***. When you're in the Multi-zoom menu, tap on the **Area View / View Preset 2** button to instantly switch the current map view of your present GPS location to a closer 3D view of an area, or neighborhood within a city, town or village around your GPS location. Main thoroughfare and highway names are displayed. Tap the **Smart Zoom** button twice to go back to the Multi-zoom menu.
- **The City View / View Preset 3 Button***. From the Multi-zoom menu, tap on the **City View / View Preset 3** button to instantly switch your present map view to a broad overview of your GPS

location. You'll see the entire city, town or village and its surrounding settlements. Main highway and road names leading to and from the locations are displayed. Tap the **Smart Zoom** button twice to access the Multi-zoom menu again.



* Learn how to create custom view presets in the [Creating Smart Zoom Menu Presets](#) section on page 32.

- [o] The Auto Zoom Button.** After you've accessed the Multi-zoom menu, tap on the **Auto Zoom** button to switch the map view of your current GPS location back to the 3D/2D Auto Zoom View. The Auto Zoom View function is the default map view mode, which is essentially a relatively close 3D street view that switches automatically to a 2D aerial view when you approach a large intersection or roundabout (for better navigating clarity), and then switches back to the 3D view once you've passed it.

Map View Location Icons and Buttons



Your Current Location Icon. This icon represents your current GPS location in Map View.



The No GPS Signal Location. This icon represents a current lack of GPS signal. It signifies the last point on the map that the application registered your GPS signal.



Your Current Location Finder Button. Any time you are away from your current GPS location in Map View, the **Current Location Finder** button appears in the middle of the lower half of the screen. Tap on it once to instantly see your current location in Map View.



The Start Point Icon

The Start Point Name Button

The Start Point Icon. The **Start Point** icon represents your trip starting point in Map View. Tapping the **Start Point** icon once transforms it into the **Start Point Name** button. You can tap on the map to return the **Start Point** icon.

The Start Point Name Button. The **Start Point Name** button shows your trip starting point's name in Map View. Tapping the **Start Point Name** button takes you to the item's Details / Route Planning / Options page. Tap the **Close** tab to return to the **Start Point Name** button in Map View. You can tap on the map to return the **Start Point** icon.




The Start Point Icon

The Start Point Name Button

The Destination Icon. The **Destination** icon represents your trip destination in Map View. Tapping the **Destination** icon once transforms it into the **Destination Name** button. You can tap on the map to return the **Destination** icon.


The Destination Name Button. The **Destination Name** button shows your trip destination's name in Map View. Tapping the **Destination Name** button takes you to the item's Details / Route Planning / Options page. Tap the **Close** tab to return to the **Destination Name** button in Map View. You can tap on the map to return the **Destination** icon.



The Via Point Icon. The **Via Point** icon represents a programmed stop along your trip route in Map View. Tapping the **Via Point** icon once transforms it into the **Via Point Name** button. You can tap on the map to return the **Via Point** icon.

The Via Point Name Button. The **Via Point Name** button shows your trip Via Point's name in Map View. Tapping the **Via Point Name** button takes you to the item's Details / Route Planning / Options page. Tap the **Close** tab to return to the **Via Point Name** button in Map View. You can tap on the map to return the **Via Point** icon.

Additional Via Points Icon. The **Additional Via Point** icon represents additional programmed stops along your trip route in Map View. The numbers increase incrementally and chronologically as you add Via Points. Tapping the **Via Point** icon once transforms it into the **Via Point Name** button. You can tap on the map to return the **Via Point** icon.



The Map Selection Point Icon. The **Map Selection Point** icon represents a location you've chosen by tapping the **Map Selection Point** button in the Smart Orientation menu and pressing a point on the map in Map View. Tapping the **Map Selection Point** icon once transforms it into the **Map Selection Point Name** button. You can tap on the map to return the **Map Selection Point** icon.

The Map Selection Point Name Button. The **Map Selection Point Name** button displays the name and location of the map point you've chosen by tapping the **Map Selection Point** button in the Smart Orientation menu and pressing a point on the map in Map View. Tapping the **Map Selection Point Name** button takes you to the item's Details / Route Planning / Options page. Tap the **Close** tab to return to the **Map Selection Point Name** button in Map View. You can tap on the map to return the **Map Selection Point** icon.



The Favorite Place Point Icon

The Favorite Place Point Name Button

The Favorite Place Point Icon. The **Favorite Place Point** icon represents the location of a Favorite Place in Map View that has not yet been defined as Start Point, Destination, Via Point or Home. Tapping the **Favorite Place Point** icon once transforms it into the **Favorite Place Point Name** button. You can tap on the map to return the **Favorite Place Point** icon.

The Favorite Place Point Name Button. The **Favorite Place Point Name** button shows you the name and the location of the Favorite Place in Map View. Tapping the **Favorite Place Point Name** button takes you to the item's Details / Route Planning / Options page. Tap the **Close** tab to return to the **Favorite Place Point Name** button in Map View. You can tap on the map to return the **Favorite Place Point** icon.



If you choose any of the options in the Route Planning Bar (**Navigate To**, **Add As Via Point**, **Add as Destination**, **Set As Start** on the Details / Route Planning / Options page, the **Favorite Place Point Name** button will change into the corresponding type of button once you're back in Map View.



The Search Result Point Icon

The Search Result Point Name Button


The Search Result Point Icon. The **Search Result Point** icon represents a search result's location in Map View that has not yet been defined as a start point, destination, via point or home. Tapping the **Search Result Point** icon once transforms it into the **Search Result Point Name** button. You can tap on the map to return the **Search Result Point** icon.

The Search Result Name Point Button. The **Search Result Point Name** button displays your search result's location and name in Map View. Tapping the **Search Result Point Name** button takes you to the search results's Location Details / Route Planning and Options page. Tap the **Close** tab to return to the **Search Result Point Name** button in Map View. You can tap on the map to return the **Search Result Point** icon.



If you choose any of the options in Route Planning Bar (**Navigate To**, **Add As Via Point**, **Add as Destination**, **Set As Start**) on the search result's Location Details / Route Planning and Options page, the **Search Result Point Name** button will change into the corresponding type of button once you're back in Map View.

Page View Buttons and Icons



The Active Route Icon

The Active Route Icon. The Active Route icon on the Route Details bar indicates that you are currently, actively navigating that route (Active route details and options can be viewed by tapping the **Route**, **Favorites** or **History** buttons in the Last Page Accessed field on the Control Bar in Map View or on the Main Menu page.)



The Inactive Route Icon

The Inactive Route Icon. The Inactive Route icon on the Route Details bar indicates that you are currently not navigating that route (Inactive route details and options can be viewed by tapping the **Route**, **Favorites** or **History** buttons in the Last Page Accessed field on the Control Bar in Map View or on the Main Menu page.)




The Pause/Resume/Record Route Button. Tapping the **Pause/Resume/Record Route** button on the Trip Display bar lets you pause and resume a navigation session (The Trip Display bar can be viewed by tapping the **Route** button in the Last Page Accessed field on the Control Bar in Map View or on the Main Menu page.) You can record and save any route you drive by first exiting any navigation sessions, then **Route** → **Pause/Resume/Record Route**.



The Favorite Place / Priority Favorite Place Button. The **Favorite Place** button appears as a blue-outlined star next to any address when viewing it's details. You can tap on the **Favorite Place** button next to the address to turn it into a **Priority Favorite Place** which is now represented by a solid yellow star. This means that the address will now be placed at the top of your Favorite Places list. Each subsequent

address that you name a Priority Favorite Place will be added to very top of your Favorite Places list. (You can view this list by tapping the **Favorites** button in the Last Page Accessed field on the Control Bar in Map View or on the Main Menu page.)



The Map Locator Button. The **Map Locator** button is always displayed next to addresses, points of interest (POI) or GPS coordinates in both the summarized info and fully-detailed info display modes. Tap on the **Map Locator** button to instantly view that item's location in Map View.



The Home Icon. The Home icon is located next to an address in both the summarized info and fully-detailed info display modes and it represents the item that you've designated as Home. This can be your actual home address, your work location, your hotel while on holiday, etc. You can set an address as home by tapping the **Set as Home** button on its Details / Route Planning / Options page. You need to have this option set to use the **Take Me Home** button in the Main Menu.

Part 2

Using the Application

Or: What happens when I press this?

Using Search






The **Search** button (Q) is always present on the Control Bar no matter where you are in the app. Tap it from anywhere in the app to go directly to the Search page.



The Cancel Button (In Landscape Mode)


To return to the Map View, tap the **Cancel** button in the far, lower left corner of the Search page when you're in Landscape View mode or by tapping the **Close** button in the upper right corner when the Search page is in Portrait View mode.

Defining Search Categories




The Search Category is set by default to All. By tapping on the **Search Category** button, you can toggle between Streets, POI, Lon/Lat and back to All.

Selecting a Country Map



The default search country is the one your Map View is currently displaying. Tap the **Select Country** button to go to the Select Country page. Tap on the specific country map you want to search. Tap the **Close** tab to save your selection and go back to the Search page.

Using the Keyboard Toggle Button




Tap the **Keyboard Toggle** button to instantly switch between input keyboards set to different languages and their corresponding writing systems.

Using the Letter/Number/Symbol Toggle Button




Tap the **Letter / Number / Symbol Toggle** button to toggle the keyboard inputs between letters, numbers and symbols.

Using the What Field



Tap in a name, street, address, POI or longitude coordinate in the What field using the keyboard. A suggested result will appear in the Suggested Result area automatically as you type.

Using the Where Field




Tap in a city or town or latitude coordinate in the Where field using the keyboard to narrow your search even further.

How to Delete a Single Space




Tap the **Delete Space** button to delete a single letter, number or space in either the What or Where fields.

How to Clear the Search Fields




Tap the **Clear Field** button (x) in the What or Where fields to delete the entire contents of either the What or Where field.

How to Get a Complete List of Search Results




Tap the **Get Search Results** button at any point in your search to hide the keyboard and display a complete list of search results.

How to Narrow Your Search Results and View Their Details




While viewing the results list, you can narrow your search even further by tapping the **Search Category** button to toggle between Streets, POI, Lon/Lat and All. Tapping on a **Search Result** will show its Location Details / Route Planning and Options page.

How to See a Search Result in Map View



Tap on the **Map Locator** button to instantly view your search result's location as a **Search Result Name Point** button in Map View.

How to Reveal the Keyboard



As your search results are being displayed, tap on the **What** or **Where** field to reveal the keyboard again.

How to Use the Location Details / Route Planning and Options Page

You Can Get to this Page in a Number of Ways

By tapping a **Map View Location Name** button or a **Location Result** on any page in the app, it will take you to the Location Details / Route Planning and Options page.

For example: From Map View: **Location Icon** → **Location Name Button** → Location Details / Route Planning and Options page or...



From the Search page: **Search Result** → Location Details / Route Planning and Options page or...

From Favorites: **Main Menu/ Control Bar** → **Favorites** → **Location** → Location Details / Route Planning and Options page... etc.

Using the Location Details Bar




The Location Details bar displays your location's full address, POI icon, GPS coordinates and other details (if available) like phone numbers. **Map Locator** → Location in Map View.



You can call the displayed **phone number** instantly by just tapping on it (if you're using a smart phone) This will, however, take you out of the application.

Using the Route Planning Bar



Depending on whether your selected location is undefined, previously defined (as a Destination, Start Point, Via Point or an undefined Search Result or Map Location Point), or if it is already part of a currently active or saved route, the Route Planning bar presents you with a variety of active and inactive buttons:

Navigate To: instantly begins guiding you to the selected location from your current GPS location.

Remove from Trip: removes the selected location from your current route.



This option appears only after the selected location has been set as a start point, via point or destination.

Add as Via Point: adds the selected location to your current route as a via point.



This option appears only when you are adding a third (or higher) location to your trip route.

Add as Destination: sets the selected location as your destination or replaces a previous destination with the selected location.

Set as Start: sets the selected location as your start point.

Using the Via Point Order Bar

VIA POINT ORDER

Move before previous

Move after next



This bar only appears on the Location Details / Route Planning and Options page when there are three or more locations on your trip route.

Move Before Previous: moves the selected location towards the beginning of your journey, i.e. just before the location preceding it.




Moving the selected location before your start point will make the selected location your new start point.

Move After Next: moves the selected location towards the end of your journey, i.e. just after the location following it.



Moving the selected location after your destination will make the selected location your new destination.

Using the Place Bar



Depending on whether your selected location is nameless, named, categorized, a favorite or set as home, the Place bar will present you with a number of buttons:

Find Closest POI: Find the closest Points Of Interest (POI) to your selected location. **Find Closest POI** → Closest POI page - where nearby Points of Interest (hotels, petrol stations, restaurants, etc.) are automatically listed according to their proximity to your selected location. Tap on a **POI Location** to go to its Location Details / Route Planning and Options page. To further refine your POI results: **Select Category** → Select Category page where all POI are selected by default. Individually **select** and **deselect** or **Deselect All** categories. **Close** to go back to the, now modified, Closest POI page. **Select Category** will now reflect your POI selection preference (i.e. Petrol Station, Multiple, All, etc.)

Categories: Designate your selected location as **Business**, **Family** or **Friends**.



- You can select multiple categories, one or none.
- This option only appears after you've saved a location as a Favorite.

Add Name/ Rename: Add or rename and save a name for your selected location. **Add Name** or **Rename** → **Input Keyboard** → Tap in a new name → **Save** → Location Details / Route Planning and Options page. The new name appears in bold lettering as the top line of your selected favorite location.



This option appears only after you've saved a location as a Favorite.

Add to Favorites: Add the selected location to your list of Favorites.

Remove from Favorites: Remove the selected location from your list of Favorites.



This option appears only after you've saved a location as a Favorite.


Set as Home: Set the selected location as Home.

Remove Home Address: Remove the Home designation from the selected location.



This option appears only after you've saved a location as Home.

Getting out of this Page



To exit the Location Details / Route Planning and Options page: **Map Locator** → Map View or **Close** → which takes you back to wherever it is that you came from (e.g., Route, History, Favorites, Map View, etc.)

Creating Smart Zoom Menu Presets

You can create up to three custom View Presets. First, in the Map View, zoom, tilt and pan the map view to your liking. Second, tap the **Smart Zoom** button twice to access the Multi-zoom Menu and press and hold the **100**, **10** or **1** button for a few seconds.



The Save View bar will appear at the bottom of the screen asking you to confirm or disregard your choice. Tap the **Choose** button to confirm your choice or the **Close** button to exit without saving.

Restoring Defaults



The Restore Defaults Button:


To restore the default City, Area and Block Views go **Settings** → **Restore Defaults** → **Yes**



Selecting the Restore Defaults option will not only reset your Multi-zoom Menu, but will restore everything in the application to its original, factory setting.


Using the Main Menu

How to Get to the Main Menu and Where I Can Go from There.



Open the Main Menu Page by tapping the **Main Menu** button (•••). From here you can continue to the six main menu buttons (**Take Me Home**, **Route**, **Favorites**, **History**, **Settings** and **Store**) or tap the **Map View**, **Search** or **Close Application** buttons on the Control Bar to go to the corresponding screens and pages.

Using Take Me Home



Go **Main Menu** → **Take Me Home** at any time to be guided from your current location to your previously designated Home location. If you are in an active navigation session, the Cancel Current Route window will appear. Select **Yes** to immediately start being guided to your Home location.




It's necessary to set a location as Home before you can utilize the Take Me Home function.

Using Route Options



The Trip page bars, buttons and displays covered in the Using Route Options section are described as they would look if you've previously set a route with a Start Point, Via Point and Destination. If you need to set a route and don't know how, follow the Quick Start and Simple Navigation instructions on page 3.

Getting to the Trip, Dashboard and Directions Page




Go **Main Menu** → **Route** → Trip page where you can view the Current Trip Status and Control bar, Current Route Details Display Page and the Route Options bar.

Go **Main Menu** → **Route** → Trip page → **Left** tab → Dashboard page


Go **Main Menu** → **Route** → Trip page → **Right** tab → Directions page

Using the Current Trip Status and Control Bar



The Current Trip Status and Control bar on the Trip paged displays your estimated travel time, estimated route distance, actual travel time and actual travel distance. You can pause your navigation session at any time by tapping the **Pause / Resume / Record Route** button. You can also use the Current Trip Status bar to record your driving when you are not in an active navigating session by tapping the **Pause / Resume / Record Route** button once. Tap it again to pause the recording of your drive.

Using the Current Route Details Display Bar




The Current Route Details Display bar on the Trip page shows you your start point, via points and destination. It also shows the estimated route distance and estimated travel time between each stop. The Active Navigation indicator shows whether your navigation route is active (yellow) or inactive (white).

By tapping the **Map Locator** button next a location you can instantly view the chosen location in the Map View.

By tapping the **Map Locator** button next to the Active Navigation indicator, Estimated Distance and Time Display, your entire route will be displayed as a 2D aerial map view.

Tap on any **Location** on the Trip Page to access its Location Details / Route Planning and Options page.

Using the Route Planning Bar



Here you can view your entire trip by stops and stages.

To see the a location or portion of your route in Map View: **Map Locator** → Map View

Tap on any **Location** to view its Location Details / Route Planning and Options page to access the following.

ROUTE PLANNING

- Navigate to
- Remove from trip
- Add as via point
- Add as destination
- Set as start

So, **Location** → Location Details / Route Planning and Options page → **Remove from Trip**: removes the selected location from your current route.



This option appears only after the selected location has been set as a start point, via point or destination.
Add as Via Point: adds the selected location to your current route as a via point.



This option appears only when you are adding a third (or higher) location to your trip route.

Add as Destination: sets the selected location as your destination or replaces a previous destination with the selected location.

Set as Start: sets the selected location as your start point.

Using the Via Point Order Bar

VIA POINT ORDER

Move before previous

Move after next

OK, we're still on the Location Details / Route Planning and Options page. Scroll down to the Via Point Order bar.

Move Before Previous: moves the selected location towards the beginning of your journey, i.e. just before the location preceding it.




Moving the selected location before your start point will make the selected location your new start point.

Move After Next: moves the selected location towards the end of your journey, i.e. just after the location following it.



Moving the selected location after your destination will make the selected location your new destination.

Using the Place Bar



And we're still on the Location Details / Route Planning and Options page. Scroll down past the Via Point Order bar to the Place bar. Depending on whether your selected Location is nameless, named, categorized, a favorite or set as home, the Place bar will present you with a number of buttons:

Find Closest POI: Find the closest point of interest to your selected location. **Find Closest POI** → Closest POI page - where nearby Points of Interest (hotels, petrol stations, restaurants, etc.) are automatically listed according to their proximity to your selected location. Tap on **POI Location** to go to its Location Details / Route Planning and Options page.

To further refine your POI results: **Select Category** → Select Category Page where all POI are selected by default. Individually **select** and **deselect** or **Deselect All** categories. **Close** to go back to the, now modified, Closest POI page. **Select Category** will now reflect your POI selection preference (i.e. Petrol Station, Multiple, All, etc.)

Categories → Choose Categories page → **Business, Family** or **Friends**. **Close** → Location Details / Route Planning and Options page.



You can select multiple categories, one or none.



This option only appears after you've saved a location as a Favorite.

Add Name/ Rename: Add or rename and save a name for your selected location. **Add Name** or **Rename** → **Input Keyboard** → Tap in a new name → **Save** → Location Details / Route Planning and Options page. The new name appears in bold lettering as the top line of your selected Favorite Location.



This option appears only after you've saved a location as a Favorite.

Add to Favorites: Add the selected location to your list of Favorites.

Remove from Favorites: Remove the selected location from your list of Favorites.



This option appears only after you've saved a location as a Favorite.


Set as Home: Set the selected location as Home.

Remove Home Address: Remove the Home designation from the selected location.



This option appears only after you've saved a location as Home.

Using the Route Options Bar



Location Details / Route Planning and Options page → **Close** → Trip page. Scroll down to the Route Options Bar → **Type and Avoidance** → Route Type page.

You can select either **Fastest** or **Shortest Route**.

The Avoid bar lets you choose one, several or all avoidance options: **Highways**, **Toll Roads**, **Unpaved Roads** and **Ferries**.



When available, a country or city-specific avoidance bar will appear below the the Avoid bar.

Close → Route Options Bar → **Reverse Route** to go back exactly the way you came. Your destination is now your start point and your start point is now your destination.

Save Route saves your route to your list of Favorite Routes. Scroll down to the bottom of the Trip page.

Start Shop Demo will begin a simulated turn-by-turn navigation session in Map View.


From the Map View Control Bar, tap **Route** in the Last Page Accessed field to go back to the Trip page.

Stop Shop Demo to stop the simulated turn-by-turn navigation session in Map View.

From the Map View Control Bar, tap Route in the Last Page Accessed field to go back to the Trip page.

Delete This Route → **Yes** removes the current route as your active navigation route, but does not remove it from your Favorites.

Reading the Dashboard



Route → Trip page → **Left** tab → Dashboard page

The Dashboard has no tappable buttons, but it tells you a lot of useful information. It features a speedometer, compass, altimeter, a precision GPS signal strength indicator and your current GPS coordinates.

Using Directions


Route → Trip page → **Right** tab → Directions page

Here you can view your route directions as a list of turn-by-turn textual descriptions with corresponding descriptive icons in sequence, their corresponding Map View by tapping **Map Locator** next to them or



Individual Directional Description → Individual Directional Description Details page, which displays the descriptive icon, textual directional description, estimated time and distance to your next navigation instruction.

Map Locator → Map View, where you can see the selected directional description or **Next** or **Previous** to view the next or previous directional description on its Individual Directional Description and Details page or **Close** to go back to the Directions page.






While in the Route pages, you can tap the **Map View** button on the Control Bar at any point to return to the Map View. Tap the **Search** button on the Control Bar at any point to go to the Search page. Tap the **Main Menu** button on the Control Bar at any point to return to the Main Menu.

Using Favorites

Creating a Favorite Place




The Map Selection Point Name Button

From Search: Tap on any **Search Result** or Map View **Location** to view its Location Details / Route Planning and Options page. Scroll down to the Place bar and tap **Add To Favorites**.


From Map View → **Location Icon** → **Location Name** button → Location Details / Route Planning and Options page. Scroll down to the Place bar and tap **Add To Favorites**.

Creating a Favorite Route



Once you've created a route, you can save it as a Favorite Route: **Main Menu** → **Route** → **Save Route**

Getting to the Favorite Places and Favorite Routes Pages




Go **Main Menu** → **Favorites** → Places

Go **Main Menu** → **Favorites** → Places → **Right** tab → Routes

Using Favorite Places

Here you can view your favorite places in the order that you saved them. You can bring a favorite to the top of the list by tapping the blue-outline star **Favorite** button, turning it into a solid-yellow star **Priority Favorite** button. You can toggle between the **Favorite** and **Priority Favorite** button by simply tapping on it.



Tap on **Select Category** to go the Select Category page where you can narrow your favorite places list according to **Business**, **Family** or **Friends**. Tap **Close** to go back to the Places page. The **Select Category** button will read All, Business, Family or Friends, depending on what you've chosen as your display criterion.


Tap on a **Location** itself to go to its Location Details / Route Planning and Options page.



Please refer to pages 27–32 to view how to use the Location Details / Route Planning and Options page.

Tap the **Map Locator** next to a favorite place to see it in Map View.

Using Favorite Routes



Tap on a **Favorite Route** to view it in the Route page where you can see the Route's Details Display bar, which shows you your start point, via points and destination. It also shows the estimated route distance and estimated travel time between each stop. The Navigation indicator shows you that your route is currently inactive (white).

By tapping the **Map Locator** button next a location you can instantly view the chosen location in the Map View.

In Map View tap **Favorites** in the Last Page Accessed field on the Control Bar to go back to the Route Details Display bar on the Route page.

By tapping the **Map Locator** button next to the Inactive Navigation Indicator, Estimated Distance and Time display, that stage of your route will be displayed as a 2D aerial map view.

In Map View tap **Favorites** in the Last Page Accessed field on the Control Bar to go back to the Route Details Display bar on the Route page. Scroll down the Route page to the Options bar where you can make the favorite route your current route by tapping **Set as Current Route**.

You can remove the displayed route from your favorites by tapping **Remove** on the Options bar.


Tap on any **Location** on the Route page to access its Location Details / Route Planning and Options page.



Please refer to pages 27–32 to view how to use the Location Details / Route Planning and Options page.

Using History


Getting to the Destinations and Trip Log Pages



Go **Main Menu** → **History** → Destinations

Go **Main Menu** → **History** → Destinations → **Right** tab → Trip Log

Using Destinations



View a list of all your destinations for the last 30 days. Tap on any destination **Location** to access its Location Details / Route Planning and Options page.




Please refer to pages 27–32 to view how to use the Location Details / Route Planning and Options page.


Using the Trip Log

The Current Trip bar shows you how far, long and the average speed at which you've travelled on your current trip.

The Trips bar lists (up to the past 30 days) the dates of your trips as **Trip Date** buttons that you can tap that will take you each specific Trip Date Details page. Your total travelled distance and average speed for that date are displayed on the **Trip Date** button as well.



Tap on any **Trip Date** button to go to that date's Trip Date Details page where you can view Individual Trip Time bars. You can lock any trip by tapping the **Lock** button. This will keep the locked trip in your Trip Log while the other, unlocked ones, are erased automatically after 30 days. Tap on any **Location** or **Route** to view it's Location Details / Route Planning and Options page.



Export any trip as a KML file by tapping the **Export as KML** button.


You can delete all of your Trip Logs, except of course the ones you've previously locked, by tapping **Delete All Logs**.



Please refer to pages 27–32 to view how to use the Location Details / Route Planning and Options page.

Creating Settings

Getting to the Settings and About Page




Go **Main Menu** → **Settings** → Settings

Go **Main Menu** → **Settings** → Settings → **Right** tab → About


Using the Settings Page

Selecting Your Language




Select Language → Select Language page → Language

Selecting Your Voice




Select Voice → Select Voice page → Voice

Selecting You Distance and Speed Units



Select Units → Select Units page → Units

Selecting Additional Keyboards



Keyboards → Additional Keyboards page → Keyboard(s)

Restoring the Factory Settings



Restore Defaults → Yes

Using the About Page

About

The About page displays Version, **Copyright**, **Safety Agreement** and **Installed Content** (**Base Map**, **User Interface Language Packs**, **Voice**, etc.) information.

Check for Updates and Recover Content


Scroll down to the bottom of the About page. Tap the **Check for Updates** button to get the latest version of Mireo DON'T PANIC.

Tap the **Recover Content** button in case you've unintentionally erased a map or other content, or it's been corrupted in some way. You'll be taken to the Select Content page where a list of all of the Mireo DON'T PANIC **Content** (application maps and add-ons) you've purchased for your smart phone will be listed and automatically selected. You can uncheck any **Content** or chose to recover everything. After you've made your choices, tap the **Recover Selected Content**. It will be downloaded again to your smart phone at no additional cost.

You can watch the status of your download on the Download Status bar on the Downloads page.

Your content will be listed on the Downloads page until you install it. Quit and restart the application to begin using your new content.

Using the Store




Buying Additional Content

Buy additional content (maps, add-ons, voices, etc.) by tapping the **Store** button. You'll be taken to the Store page where you'll be presented with a list of **Items**, organized by category, that you can purchase. Tap on any **Item** to view its details page where you can see when the item was last updated, its size and price. After you tap the **Buy** button, depending on your smart phone type, the **Confirm Your In App Purchase** button will appear. Tap **Buy** and you'll be guided to your store or market account where you can authenticate and confirm your purchase via your store or market's standard payment method.



- If you accidentally buy a map or add-on that you already have, the app will know and the content will not be downloaded and you will not be charged.
- If you've accidentally erased a map or add-on, you can go through the entire purchase process, but you will not be charged again for the content.



The Downloads Page

Store → **Right** tab → Downloads

After you've purchased content from the in app store, you can watch your download progress in the Downloads bar on the Downloads page. The Downloads bar features the download progress bar, the amount of mbs downloaded, the download rate, estimated download time remaining and the **Pause / Resume** button to pause and resume your download. The content being downloaded is displayed beneath the Downloads bar and features the download activity status, the name of the content and the percent of the content downloaded.

Your content will be listed on the Downloads page until you install it.

Quit and restart the application to begin using your new content.

Congratulations! You've reached the end of the User Manual and now know everything about the app!

Enjoy Mireo DON'T PANIC and remember to always drive safely!