

---

**INVOLIGHT**

## **LED Mini-flower**



**MF31**

**USER MANUAL**

---

## LED mini-flower

This product is easy to operate. It could be used after plugging into electricity.

### **Two Modes:**

Sound Active Mode

Auto Run Mode

1. This product will run by the tempo if the sound is activated
2. When the volume or sound sensitivity is low, it would not be able to activate the sound active function.
3. The product would be black out without any sound activation within 3 seconds, and it will turn to Auto Run Mode without any sound activation within 10 seconds.

### **Specific Operation:**

1. Connected to electricity safely and correctly.
2. Rotate the button to adjust the sound active sensitivity.
3. Contra rotating the potentiometer to the end, the sensitivity will be turned down, when the sound is too low to activate the sound active function, the product would be under the mode of auto run.

**INVOLIGHT**