

INVO LIGHT

MODEL UV40


Please read these instructions carefully before using this product

IMPORTANT SAFETY INSTRUCTIONS:

1. This portable lamp has a polarized attachment plug (one blade is wider than the other) as a safety feature. This plug will fit in a polarized outlet. Only one way, if the plug doesn't fit fully in the outlet, reverse the plug. If it still doesn't fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully insert. Don't attempt to defeat this safety feature, don't alter the plug. Please mount the unit on wall surface. This unit is used for recreational illumination for house.
2. Dry locations use only.
3. To reduce risk of fire, replace lamp only with 40W(Max.) T8 tube.
4. Hot surface, keep away from curtains and other combustible materials.

HOW TO INSTALL: (figure 3, figure 4)

The diameter of fixing PIN on the mounting surface shall be between 3mm and 4mm, and its PIN HEAD's diameter shall be less than 9mm.(figure 1, figure 2).



Technical Specifications :

Item Code : UV40

Name : FLUORESCENCE LIGHT-40

Power : AC240V 50HZ

Black tube : T8 40W

Size : L1235X W100 X H40mm

Weight : 2.7KG

HOW TO OPERATE:

1. Plug unit into AC power outlet.
2. Turn on the rocker switch on black light enclosure to lighten on.
3. Unplug the unit from AC power outlet for a long idleness.

WARNING:

1. To reduce risk of fire and electric shock, don't cover the unit when it is in use.
2. The unit is not a toy, keep out of children's reach.
3. The unit will get hot during use. Turn off the apparatus and to cool for five minutes prior to touching the unit or replace fluorescent tube.

CAUTION :

To reduce the risk of fire, electric shock or injury to persons:

1. Use only insulated staples or plastic ties to secure cords.
2. Route and secure cords so that they will not be pinched or damaged when the cabinet is pushed to the wall.
3. Position cabinet light with respect to cabinet so as to permit reading of the lamp replacement Markings during relamping,
4. Not intended for recessed installation in ceilings.
5. Not intended for surface installation inside built-in furnishings such as kitchen cabinets, china cabinet, or trophy cases.
6. The portable cabinet light may be installed under a kitchen cabinet when the power supply cord is not concealed or run through openings in the cabinet.
7. Do not conceal power supply cord (or power supply) inside a wall, ceiling, soffit, kitchen cabinet, or similar permanent structure.
8. Do not run the power supply cord through holes in walls, ceilings, or floors.

