

WARNING


Driving while distracted can result in loss of vehicle control, crash and injury. We strongly recommend that you use extreme caution when using any device that may take your focus off the road. Your primary responsibility is the safe operation of your vehicle. We recommend against the use of any hand-held device while driving and encourage the use of voice-operated systems when possible. Make sure you are aware of all applicable local laws that may affect the use of electronic devices while driving.



United States
Lincoln Customer Relationship Center
1-800-521-4140
(TDD for the hearing impaired 1-800-232-5952)
lincolnowner.com

Canada
Lincoln Customer Relationship Centre
1-800-387-9333
lincolncanada.com

This Quick Reference Guide is not intended to replace your vehicle Owner's Manual which contains more detailed information concerning the features of your vehicle, as well as important safety warnings designed to help reduce the risk of injury to you and your occupants. Please read your entire Owner's Manual carefully as you begin learning about your new vehicle and refer to the appropriate chapters when questions arise. All information contained in this Quick Reference Guide was accurate at the time of duplication. We reserve the right to change features, operation and/or functionality of any vehicle specification at any time. Your Lincoln dealer is the best source for the most current information. For detailed operating and safety information, please consult your Owner's Manual.



Lincoln MKS
January 2014
Second Printing
Quick Reference Guide
Litho in U.S.A.
EA5J 19G217 AA

2014 MKS



Quick Reference Guide



THE LINCOLN MOTOR COMPANY

Commonly Used Voice Commands

SYNC® Say the Word.

Table of Contents

2014 MKS

Touch the voice button  on the right-hand side of your steering wheel and then say:



Basic Commands

- ▶ What can I say?
- ▶ List of commands
- ▶ Main menu
- ▶ Previous
- ▶ Next
- ▶ Go back
- ▶ Exit
- ▶ Help
- ▶ Vehicle health
- ▶ Pair my phone



Phone

- ▶ Phone list of commands
 - Dial
 - Call <name> on cell/at home/at work
 - Call voicemail
 - Do not disturb <On/Off>
 - Listen to text messages (phone-dependent feature)



Climate

- ▶ Climate control list of commands
 - Climate <On/Off>
 - Climate my temperature
 - Climate temperature



SYNC Services*

Must say "Services" first, and then "What can I say?"

- ▶ Traffic
- ▶ Directions
- ▶ Business search
- ▶ Operator (for direction or business search)
- ▶ Favorites
- ▶ News, sports, weather, horoscopes, stock quotes, movies or travel
- ▶ Help



Entertainment

- ▶ Audio list of commands: You can also get detailed lists of commands for radio, USB, **Bluetooth**® audio, SiriusXM and SD card
- ▶ Audio <On/Off>
- ▶ Radio
 - FM <87.9-107.9>
 - FM preset <#>
- ▶ CD
 - Play track <1-512>
 - Shuffle <On/Off>
- ▶ USB
 - Play song <name>
 - Play album <name>
- ▶ SiriusXM
 - <Channel name>
 - Preset <#>



Navigation*

- ▶ Navigation list of commands
 - Destination street address <number, name, city>
 - Destination home
 - Navigation voice <On/Off>
 - Navigation volume <increase/decrease>
 - Repeat instruction
 - Show <map/north-up/heading-up/3D>
- ▶ Travel Link list of commands
 - Traffic
 - Weather
 - Movie listings
 - Fuel prices
 - Sports <headlines/scores/schedule>

*if equipped

Instrument Panel4-5

SYNC with MyLincoln Touch..... 6-9

Convenience 10

Comfort11

Essential Information 12-13

Function14-15

Learn More About Your New Vehicle



lincolnowner.com




lincolncanada.com

Learn How to SYNC Your Ride

SYNC is a voice-activated technology personalized by you. It is a hands-free, voice recognition system used for entertainment, information and communication.

SyncMyRide.com (U.S.) or SyncMyRide.ca (Canada)


Some services may not be available in your area. For additional support, refer to your Owner's Manual, visit the website or call the toll-free number. **U.S. customers:** Visit SyncMyRide.com or call **1-800-392-3673** (select Option 1 or 2 for language, then press 3). **Canadian customers:** Visit SyncMyRide.ca or call **1-800-565-3673** (select Option 1 or 2 for language, then press 3).



Instrument Panel

2014 MKS

1 Adaptive Headlamps

The headlamp beams move in the same direction as the steering wheel, providing more visibility when driving around curves. Active at speeds above 3 mph (5 km/h), it has a power-up movement check feature. When you start your vehicle, the lamps track left to right, then back to center. To use, place the lighting control switch into the autolamp position .

2 Power Tilt/Telescope Steering Column

Your power tilt steering column has a 4-way rocker control, allowing you to adjust the steering wheel to the desired position.

3 Adaptive Cruise Control*


In addition to cruise control, Adaptive Cruise Control* allows you to set a 'gap distance' between your vehicle and the vehicle in front of you during highway driving. When your cruise control is active, press **GAP** up or down to select the gap distance. Refer to the **Cruise Control** chapter of your **Owner's Manual** for more information.

Note: Driving aids do not replace the need to watch where the vehicle is moving and brake where necessary. Refer to your **Owner's Manual** for safety information, more details and limitations.

4 Left Information Display

Provides information about various systems on your vehicle. Use the left-hand 5-way controls located on the steering wheel to choose and confirm settings and messages. Refer to the **Information Displays** chapter in your **Owner's Manual** for more information.

5 Service Engine Soon Light

 Lights briefly when you switch the ignition on. If it remains on or is blinking after starting the engine, the On-Board Diagnostics (OBD-II) system has detected a malfunction. Drive in a moderate fashion and contact your authorized dealer as soon as possible.


6 Right Information Display

Provides information about Entertainment, Phone and Navigation*. Use the right-hand 5-way controls located on your steering wheel to scroll through, highlight and make minor adjustments within a selected menu. Refer to the **MyLincoln Touch™** chapter in your **Owner's Manual** for more information.

7 Steering Wheel Audio Controls

Press **VOL +/-** to increase/decrease volume levels. Press **SEEK ▲ / ▼** to access the next/previous radio

station preset, CD track or preset satellite radio channel*.

Press  to access SYNC® phone features.

Press  to access voice recognition.

8 Push-button Start

Allows you to start your vehicle by pressing the **ENGINE START/STOP** button while fully pressing down on the brake pedal. Press the button again to switch the engine off. If your vehicle has been idling for an extended period of time, it will automatically shut down, unless the driver overrides it. The information display shows an alert prior to engine shut down.

Note: Your intelligent access transmitter must be inside the vehicle for the ignition to start.

9 Hazard Control

10 Audio Volume and Fan Speed SWIPE Controls

Simply swipe your finger to adjust audio volume or fan speed with the touch sensitive slide bars.

*if equipped




Using SYNC with MyLincoln Touch

SYNC is a hands-free, voice recognition system used for entertainment, information and communication.

Use the four-corner, four-color touchscreen to explore and interact with your vehicle. The touchscreen works the same way traditional controls, knobs and buttons do.

Press the various corners on your touchscreen to personalize the many features and settings of your vehicle all in one place. The system provides easy interaction with your cellular phone, multimedia entertainment, climate controls and navigation system*.


General Tips

- ▶ Press the home  icon at any time to return to the home screen.
- ▶ For additional support, refer to your **Owner's Manual**, visit the website or call the toll-free number. See the inside front cover of this guide for more details.

Before You Get Started

- ▶ If you have the navigation SD card*, make sure that it is inserted into the media port or your navigation will not work.
- ▶ The touchscreen is sensitive, so make sure you press the desired icon accurately and firmly.
- ▶ The touchscreen is sensitive, so make sure you press the desired icon accurately and firmly.

Create Your Owner Account

1. Set up your owner account at **SyncMyRide.com** (U.S.) or **SyncMyRide.ca** (Canada). Register by following the on-screen instructions. After registering, you can see what complimentary services you are eligible for.
2. SYNC uses a wireless connection called  **Bluetooth[®]** to communicate with your phone. Turn Bluetooth mode on in your phone's menu options to let your phone find SYNC.

For more details on setting up your phone with SYNC, visit **SyncMyRide.com** (U.S.) or **SyncMyRide.ca** (Canada), or your phone manufacturer's website.

Why You Need a SYNC Owner Account

A SYNC owner account is required for Vehicle Health Report activation and the ability to view your reports online. You'll also be able to take advantage of all of SYNC's Services and personalization features, such as saving your Favorites and Points of Interest (POI). You'll receive the latest software updates that add new places, directions and information, and if you have questions, you'll get free customer support. Visit the website or call the toll-free number for more information. See the inside front cover of this guide for details.

Pairing Your Phone with SYNC

1. Make sure that your vehicle is in park (P) and your radio and ignition are turned on. Touch **Add Phone** in the upper left corner of the touchscreen.

Find SYNC appears on the screen and instructs you to begin the pairing process from your device.

2. Make sure that **Bluetooth** is set to **ON** and that your cellular phone is in the proper mode. See your phone's manual if necessary. Select SYNC, and a six-digit PIN appears on your device.
3. If you are prompted to enter a PIN on your device, it does not support Secure Simple Pairing. To pair, enter the PIN displayed on the touchscreen. Skip the next step.
4. When prompted on your phone's display, confirm that the PIN provided by SYNC matches the PIN displayed on your cellular phone.
5. The display indicates when the pairing is successful.

Note: The system may prompt you to set your phone as the primary/favorite (the primary phone will receive messages and voicemail); download your phone book (this is required to use the full set of voice commands) and/or turn on 911 Assist[®].

Tips

- ▶ Make sure you accept SYNC's request to access your phone.
- ▶ To pair subsequent phones, please refer to **Pairing Subsequent Phones** in the SYNC chapter of your **Owner's Manual**.
- ▶ If you are experiencing pairing problems, try performing a clean pairing by deleting your services from SYNC, deleting the SYNC connection from your phone, and then repeating the **Pairing Your Phone with SYNC** process.

Phone

Voice-control your phone to connect with many other features and SYNC Services:

- ▶ Connect to SYNC Services for traffic, directions, business searches and information favorites.
- ▶ Connect to Operator Assist to help locate a listing or destination.
- ▶ Call for a Vehicle Health Report.
- ▶ Connects automatically with a 911 Operator in the event of an accident (feature must be on prior to an event).
- ▶ Transfer calls seamlessly from SYNC to phone as you get in or out of your vehicle.
- ▶ Refer to the **SYNC** chapter of your **Owner's Manual** for complete details.

Using Your Phone with SYNC

Note: Enter your phone book contacts with both first and last names to increase SYNC's ability to select the correct contact. Remember to say the contact name exactly as it's listed in your phone book.

Making a Phone Call

Use SYNC to make a phone call to anyone in your phone book by pressing the voice button. When prompted, give any of the following voice commands:

Call <name>
Call <name> at work
Call <name> on mobile or cell
Call <name> at home

For example, you could say **"Call Jake Smith at home"**. SYNC repeats the command back to you and dials the number.

Note: You can also make phone calls by giving the voice command **"Dial"**, then verbally saying the phone number.

Answering Incoming Calls

Whenever you have an incoming call, you will be able to see the name and number of the person calling in your display. Press **ACCEPT** on the touchscreen or the phone button to answer an incoming call.

Ending the Call

Press and hold the phone button.

Do Not Disturb Mode

This feature blocks incoming calls and text messages, and saves them for later. You still have access to outgoing calls when this feature is active. Say the voice command **"Do not disturb on"** to enable and **"Do not disturb off"** to disable.




Navigation*

Get started with your navigation system by pressing the upper-right, green corner. The available, voice activated navigation system includes:

- ▶ SiriusXM Traffic
- ▶ SiriusXM Travel Link
- ▶ GPS (Global Positioning System) technology
- ▶ 3-D mapping
- ▶ Turn-by-turn navigation

Set a Destination

Set a destination on your touchscreen by using a street address, city center, a place on the map or a Point of Interest (POI). The easiest way, however, is by voice.

1. Press the voice button . When prompted, say **"Destination street address"**.

2. The system will ask you to say the full address and will display an example on-screen.
3. You can then speak the address naturally, such as: **"One two three Main Street, Anytown"**.

You can also use the touchscreen to enter a destination and narrow your choices by city or street as you type.

You can choose from up to three different types of routes:

- ▶ **Fastest:** Uses the fastest moving roads possible.
- ▶ **Shortest:** Uses the shortest distance possible.
- ▶ **Eco (EcoRoute):** Uses the most fuel efficient route.

Tips

- ▶ Save your favorite locations by touching **"Save to Favorites"**.
- ▶ Change your map views from Direction Headed, North Up or 3D.

Climate

Control the temperature, airflow direction, fan speed and other climate features for you and your front passenger. Say **"Climate temperature 72 degrees"** and MyLincoln Touch will make the adjustment.

Set Your Temperature

- ▶ Touch the lower-right, blue Climate corner on the touchscreen.
- ▶ Set your exact, desired temperature by using the (+) or (-) buttons.



Entertainment

No matter how you store your music, SYNC makes it yours to enjoy when you're behind the wheel. Just press the lower-left, red corner of the touchscreen. From here, you can easily go between AM/FM, SiriusXM and other media sources.

Set Your Radio Presets


- ▶ Touch the Entertainment corner on the touchscreen.
- ▶ Touch **FM**.
- ▶ Touch **Direct Tune**.
- ▶ Enter the desired station and touch **Enter**.
- ▶ Touch **Presets** and then touch and hold one of the memory preset buttons to save it. You'll hear a brief mute and the sound will return once the station is saved.

Using SYNC to Access Digital Media

SYNC has a media hub with multiple inputs, allowing you to access personal media from your digital devices. Plug in your USB media devices, such as phones and MP3 players, and use SYNC to play all of your favorite music.

Note: SYNC indexes your music; the more information that is stored on your USB device, the longer it takes SYNC to index.

Using Voice Commands to Play Music

1. Plug your media player into your USB port.
2. Press the voice button . When prompted, say **"USB"**, then follow up by saying one of the following voice commands:

Play all
Play next song
Play song <name>
Play album <name>

For more information, refer to the **MyLincoln Touch** chapter of your **Owner's Manual**. For support, visit the website or call the toll-free number. See the inside front cover of this guide for details.


*if equipped


Intelligent Access


Note: Your intelligent access transmitter must be within 3 feet (1 meter) of the vehicle for intelligent access to function properly.


To unlock and open the driver's door, pull the front exterior door handle. To lock the doors, press and hold the sensor button on the door handle.


The intelligent access transmitter also contains a mechanical key blade, which can be used to unlock the driver door, if necessary.

Press  once to lock all doors. Press again within three seconds to confirm all doors are locked. You can also use the remote to close the vehicle's windows and vent the moonroof* by pressing and holding the lock button on the remote control. Press the lock or unlock button to stop the motion.

Press  once to unlock the driver's door. Press again within three seconds to unlock all doors. You can also use the remote control to open the vehicle's windows and vent the moonroof* by pressing and holding the unlock button. The power sunscreen will also open.



Press  to activate the panic alarm. Press again or turn on the ignition to deactivate.


Press  twice within three seconds to open the trunk.

Car finder: Press  twice within three seconds to locate your vehicle. The horn will sound and the lamps will flash.

Remote Start



Remote start allows you to start the engine from outside your vehicle using your transmitter. To start, press  and then press  twice within three seconds. Once inside, apply the brake while pressing the **ENGINE START/STOP** button. Shift

into drive (D) and go. To turn the engine off from outside the vehicle after using your remote start, press  once.

Exterior Trunk Release



When your intelligent access transmitter is within 3 feet (1 meter) of the vehicle, you can open your trunk by pressing the release button located near the license plate.



MyKey®

MyKey allows you to program certain driving restrictions in order to promote good driving habits. You can program things such as speed restrictions and limited volume levels. For complete information, refer to the **MyKey** chapter in your **Owner's Manual**.


*if equipped

Climate Controlled Front Seats




To use, press the heated seat symbol  or the cooled seat symbol  located on the touchscreen to cycle through the various settings and off. Warmer or cooler settings are indicated by more indicator lights. The heated and cooled seats will only function when the engine is running.

Heated Steering Wheel*

Your vehicle may be equipped with a heated steering wheel. Press the  icon in your touchscreen to turn this feature on and off.

Note: The wood trim will not heat between the 10 and 2 o'clock positions.

Rear Heated Seats*

The rear heated seat controls are located on the rear of the center console. To use, press the heated seat button  to cycle through the various heat settings and off. Warmer settings are indicated by more indicator lights. The rear heated seats will only function when the ignition is on.

Memory Function

The memory control, located on the driver's door, allows the positioning recall of the driver's seat, power mirrors, power tilt and telescopic steering column* and adjustable pedals*. To program position **1**, press and hold the **1** button until you hear a tone. Use this same procedure to set positions **2** and **3** using the respective buttons. You can recall the set memory positions by pressing the desired memory control.

Tilting Head Restraints





Your vehicle's front-row head restraints can be adjusted. Pull up to raise the head restraint. To lower, press the head restraint down while pressing and holding the guide sleeve adjust/release button. Tilt the head restraint forward for additional comfort by gently pulling the top of the head restraint. Once it is in the forward-most position, tilting it forward once more will release it to the upright position.

Note: Do not attempt to force the head restraint backward after it is tilted. Instead, continue tilting it forward until the head restraint releases to the upright position.

Dual-panel Moonroof and Power Sunscreen*



Your moonroof and sunscreen have a one-touch, open and close feature.

To open the sunscreen, press  and release. To close, pull and release .

To open the moonroof, press and release the **SLIDE** control. The sunscreen will open automatically. To close, pull and release the **SLIDE** control.

To vent the moonroof, press and release the **TILT** control. To close, pull and release the **TILT** control.

To stop motion at any time, press the control a second time.

*if equipped



THX II® Certified Audio System*

Fourteen strategically positioned, high-performance speakers deliver a home theater sound right in your vehicle. The system will automatically make adjustments to volume and sound distribution, based on vehicle speed and external road noise.



Easy Fuel® System

With this system, push to release the fuel door, insert the nozzle and begin fueling. It is self-sealing and therefore protected against dust, dirt, water, snow and ice. Wait 10 seconds from the time the refueling nozzle is shut-off until you remove the nozzle from the

vehicle to allow residual fuel in the nozzle to drain into the tank. When using a portable fuel container, slowly insert the fuel funnel (located in the spare tire compartment) and pour the fuel into the funnel.


Note: Do not use aftermarket funnels as they will not work with the Easy Fuel system and may cause damage. Properly clean the funnel after each use.

Autowipers

If activated, your wipers will automatically turn on when moisture is present on the windshield. The wiper speed will vary based on the amount of moisture detected and the sensitivity setting. To deactivate, turn your wiper controls off.

Note: Make sure that this feature is turned off before entering a car wash.

*if equipped



Fuel-efficient Transmission

Your vehicle has been designed to improve fuel economy by reducing fuel usage while coasting or decelerating. This may be perceived as a light to medium braking sensation when removing your foot from the accelerator pedal.

Fuel Tank Capacity/Fuel Info

Your vehicle has a 19.0 gallon (71.9L) fuel tank. Use only **UNLEADED** fuel or **UNLEADED** fuel blended with a maximum of **15% ethanol**. Do not use fuel ethanol (E85), diesel, fuel-methanol, leaded fuel or any other fuel because it could damage or impair the emission control system.

Towing

Towing your vehicle behind an RV or any other vehicle may be limited. Refer to the **Towing the Vehicle on Four Wheels** section in the **Towing** chapter of your **Owner's Manual** for more information.

Rear Window Buffeting

When one or both of your rear windows are open, you may hear a wind throb or buffeting noise. To alleviate this, lower a front window until the buffeting subsides.

Collision Warning System*



This system is designed to alert the driver of certain collision risks. Radar sensors detect if vehicles ahead of you, which are moving in the same direction, may be a collision risk. The system will alert you with an audible tone and red warning light which will appear above the dash. If the risk of collision increases, the system will increase brake support to help reduce collision speed.

Location of Spare Tire and Tools

Your spare tire and tools are located beneath the carpeted floor panel in the trunk of your vehicle. The spare tire is designed for emergency use only and should be replaced as soon as possible. For complete details on changing your tire, refer to the **Changing a Road Wheel** section in the **Wheels and Tires** chapter of your **Owner's Manual**.

Tire Pressure Monitoring System

Your vehicle has a tire pressure monitoring system that shows a low tire pressure warning light (ⓘ) in your instrument cluster when one or more of your tires is significantly under-inflated. If this happens, stop and check your tires as soon as possible. Inflate them to the proper pressure. Refer to the **Inflating Your Tires** section in the **Wheels and Tires** chapter of your **Owner's Manual** for more information.

Roadside Assistance

Your new Lincoln vehicle comes with the assurance and support of 24-hour emergency roadside assistance.

To receive roadside assistance in the United States, call **1-800-521-4140**. In Canada, call **1-800-387-9333**.

*if equipped



Rear View Camera*

This system provides a video image of the area behind the vehicle. The display automatically appears in the touchscreen when the vehicle is in reverse (R) and uses green, yellow and red guides to alert you of your proximity to objects.

Forward and Reverse Sensing Systems

This system sounds an audible warning tone if there is an obstacle near the vehicle's front or rear bumpers. As the vehicle moves closer to the obstacle, the rate of the warning tone increases in frequency. The front sensors are automatically activated when the gearshift is in any position other than park (P) or neutral (N) and the vehicle speed is below 7 mph (12 km/h). The system detects certain objects while the transmission is in reverse (R) and will detect objects up to 6 feet (2 meters) away. See the **Parking Aids** chapter in your **Owner's Manual** for complete information on your vehicle's sensing systems.



SelectShift Automatic® Transmission

Your SelectShift automatic transmission gives you the ability to manually change gears, if you like. To use SelectShift, move the gearshift lever into sport (S). Use the paddle shifters, located on the steering wheel, to manually select gears. Pull (+) to upshift, pull (-) to downshift. Return the gearshift lever to drive (D) when manual control is no longer desired.



Lincoln Drive Control

This suite of electronic vehicle systems continuously monitors both your inputs and the road conditions to optimize ride comfort, steering, handling, powertrain response and sound. Choose your custom driving experience through the information display under **Settings**, **Drive Assist** and then **Drive Control**:

- ▶ **Comfort:** provides drivers with easier steering and a more fluid suspension.
- ▶ **Normal:** delivers a more engaging drive experience with confident handling and a powerful, yet quiet powertrain sound.
- ▶ **Sport:** adds a sporty feel with a stiffer suspension and an emphasis on handling and control, along with a more powerful engine tone.

*if equipped

Active Park Assist*

Detects an available parallel parking space and automatically steers the vehicle into the space (hands-free) while you control the accelerator, gearshift and brakes. The system visually and audibly instructs you to park your vehicle.

To use active park assist, press the **AUTO IPI** button located near the shifter. Use the direction indicator to indicate which side of the vehicle you want the system to search on. If the direction indicator is not on, the system automatically searches on the vehicle's passenger side. To stop the parking procedure, grab the steering wheel or press the control again. For complete information, refer to the **Parking Aids** chapter of your **Owner's Manual**.

Note: The driver is always responsible for controlling the vehicle, supervising the system and intervening, if required.

SecuriCode™ Keyless Entry System



Allows you to lock or unlock the doors, recall memory features and arm or disarm the anti-theft alarm. To get started, you will need your five digit factory code found on your owner's wallet card (located in the glove box). Entering this code unlocks the driver's door. To lock all doors, press and hold **7-8** and **9-0** at the same time. For complete information, refer to the **SecuriCode Keyless Entry Keypad** section in the **Locks** chapter of your **Owner's Manual**.

BLIS® (Blind Spot Information System) with Cross Traffic Alert*



BLIS uses radar sensors to help you determine if a vehicle may be in your blind spot zone. The cross traffic alert feature warns you of vehicles approaching from the sides when the transmission is in reverse (R). BLIS and cross traffic alert will display a yellow indicator light in your exterior mirrors and the cross traffic alert will also sound tones and display messages to warn you which direction vehicles are approaching. Refer to the **Driving Aids** chapter in your **Owner's Manual** for more information.

Note: Visibility aids do not replace the need to watch where the vehicle is moving. Refer to your **Owner's Manual** for safety information, more details and system limitations.

Lane Keeping System*

The system detects unintentional drifting toward the outside of the lane and alerts or aids the driver to stay in the lane through the steering system and instrument cluster display. The system automatically detects and tracks the road lane markings using a camera that is mounted behind the interior rearview mirror.

*if equipped