



NOUS VIVONS SAIN
We live healthy

VITESSE® *Home*



PROFESSIONAL HAIR STRAIGHTENER
ПРОФЕССИОНАЛЬНЫЕ ЩИПЦЫ
ДЛЯ ВЫПРЯМЛЕНИЯ ВОЛОС



“Vitesse France S.A.R.L” (Витессе, Франция)
91 Rue De Фоборг Сант Хонор, Париж 75008, Франция
Сделано в Китае

www.vitesse.ru



VS-909

En

DEAR CUSTOMER!

You have made an excellent decision. Vitesse home range offers you an exclusive, high quality range of appliances for your ultimate home luxury and healthy living.

Instructions for Use

The Professional Hair Straightener is ideal for personal use at home. Ceramic hot plates ensure equal heat distribution, relaxing the hair and creating a shiny, smooth finish. The Professional Hair Straightener is suitable for all hair types-thick, fine, natural, curly or colored.

Please read the following instruction carefully before use.

SAFETY FIRST

- ENSURE the cord is in perfect condition. If there is any damage to the cord, the appliance must NOT be used until the cord is replaced.
- NEVER allow the ceramic hot plates to touch your skin while the Hair Straightener is plugged in.
- NEVER use the Hair Straightener in the bathroom or any area where it could come into contact with water or liquid.
- NEVER cover the Hair Straightener when it is plugged in.
- NEVER leave the Hair Straightener unattended when it is plugged in.
- ALWAYS keep the Hair Straightener's power supply cord away from the ceramic hot plates.
- ALWAYS keep the Hair Straightener out of reach of children.

HOW TO USE:

- Plug in the Hair Straightener and place on a smooth, dry, flat surface.
- Use lower temperature for fine or bleached hair, medium temperature for normal hair and higher temperatures for thick, coarse or ethnic hair.
- Turn ON/OFF switch to Switch ON the unit. The red and green lights go on indicating that the appliance is heating up. After approximately 5 minutes, the red light will turn off indicating the appliance has reached the correct temperature for use.
- Starting at the top of the head, next to the scalp, select a small section of hair (approx. 2 inches wide and 1/4 inch deep) and clamp between the ceramic plates. Maintaining some tension, slowly slide the tongs down the section of hair from roots to tips. Be careful to avoid touching your hands or scalp with the hot plates.
- Repeat process all over the head, allowing hair to cool before combing through.
- After use, push ON/OFF switch to switch OFF the unit. The green light goes off, indicating that the appliance is cooling down.
- When the Hair Straightener has completely cooled, clean with a damp, soft cloth. Do not use chemical cleaners.

Ru

УВАЖАЕМЫЕ ПОКУПАТЕЛИ! ВЫ ПРИНЯЛИ БЛЕСТЯЩЕЕ РЕШЕНИЕ!

Фирма Vitesse предлагает Вам гамму эксклюзивных высококачественных приборов для несомненно роскошного и здорового образа жизни.

Перед первым использованием прибора внимательно прочитайте инструкции, описанные ниже.

ФУНКЦИИ

- Выпрямляет волосы
- Защищает волосы и сохраняет цвет

ПРЕИМУЩЕСТВА

- Щипцы для выпрямления волос легкие в эксплуатации
- Прибор оснащен высокой технологией при помощи которой щипцы быстро нагреваются и поддерживают постоянную рабочую температуру.
- Создают комфорт и придают волосам блеск

ТЕХНИЧЕСКИЕ ХАРАКТЕРИСТИКИ

- Напряжение: AC 110-220В / 60Гц - 36Вт
- Температура: 120°C - 200°C

ЭКСПЛУАТАЦИЯ

- Подключите штепсельную вилку к сетевой розетке.
- Настройте кнопку терморегулятора на желаемый температурный режим.
- Высококачественная керамическая пластина быстро нагревается
- Пластина сохраняет постоянную температуру.

Профессиональные щипцы эффективно выпрямляют волосы в любом состоянии. Однако, для достижения оптимального результата перед тем как использовать щипцы, рекомендуется вымыть волосы, слегка просушить, но так что бы они оставались влажные.

ВНИМАНИЕ

- Не погружайте прибор в воду.
- Не прикасайтесь к пластинам, когда они горячие.
- Не кладите нагретые щипцы на пластмассовые и термочувствительные поверхности.
- Храните в недоступном для детей месте.
- Не применяйте прибор с поврежденным шнуром питания, штепсельной вилкой или другими поломками.

Утилизация старого оборудования



Вы можете помочь защитить окружающую среду!
Электрические устройства должны утилизироваться в специальных местах, указанных местными органами власти.

Срок службы товара не менее 2-х лет, при соблюдении условий эксплуатации